CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.

The use of steam or water-based cleaners may cause excessive shrinking or staining.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Parts List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
А	Seat		1X
В	Front leg		2X
С	Back leg		2X
HW1	Socket bolt 8 x 1 x 55 mm	()	6X
HW2	Socket bolt 8 x 1 x 70 mm	()— <u></u>	4X
HW3	Flat washer 8,5 mm	0	10X
HW4	Allen key		1X



Model# ACH4502

Product Dimensions:26.77"*27.95"*31.89"



Weight Capacity: 275 lbs

WARNING: DO NOT STAND ON CHAIR

WARNING: DO NOT OVER TORQUE BOLTS/SCREWS







PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key











