## **WARNING**

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN. WARNING \*\*\* SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL. ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

### **CARE AND MAINTENANCE**

To clean the outside of the fixture, use a dry or slightly dampened clean cloth (use clean water, never a solvent) to wipe the surface of the fixture.

To clean the inside of the fixture, first disconnect power to the fixture by turning off the circuit breaker or by removing the fuse at the fuse box. Next, use a dry or slighly damperned clean clorth (use clean water, never a solvent) to wipe the interior surface of the fixture.

Do not use any cleaners with chemical, solvents or harsh abrasives. Use only a dry soft cloth to dust or wipe carefully.

### **NOTICE& IMPORTANT SAFETY INSTRUCTIONS**

- \* Please make sure that you have all parts indicated before you begin assembly of this item
- \* This item should be assembled on a soft surface to prevent scratching the finish during assembly
- \* To reduce the risk of fire, electrical shock or injury to persons or property, please follow the guideline below for safe use and installation
- \*The external flexible cable or cord of this lamp cannot be replaced
- \*If the cord is damaged, the lamp shall be destroyed


#### **Part List and Hardware List**

PIECE	DESCRIPTION	PICTURE	QUANTITY	PIECE	DESCRIPTION	PICTURE	QUANTITY
А	Lamp shade		1X	С	Charging cable		1X
В	Lamp body		1X				



Model#: JYL7167


Product Dimensions: 6.25"Lx6.25"Wx17.5"H



# **PREPARATION**

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product. Estimated Assembly Time: 10 minutes.


If there are any questions relating to defects, missing parts, assembly issues, replacements, or device connectivity issues, please send a detailed email to cs@jonathany.com



dimmer switch and indicator light USB Micro charge port (USB Type-C) USB Type-A

Step2:1.One end of the charging cable (C) is connected to the lamp body (B) USB Micro charge port (USB Type-C) and the other end is connected to the charging plug (5V 2A)(not |1.Press the switch once to turn on or off. included).

2. When charging, the indicator light is green color. 3. When fully charged, the indicator light is blue color. 4. The USB Type-A connector is for emergency, temporary use only and can't be used for long term charging of the phone.



**Step3:** Touch Dimmer Switch

- 2. Press and hold the switch for adjusting the brightness.
- 3. Memory function: Press the switch once after brightness adjustment to turn the light off. Press switch once again to resume the same brightness setting.

Put the light on a level surface to check if everything is stable.