


ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



Allen Key

(Included)



Phillips
Screwdriver

(Not Included)



2 - Persons
Recommended

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING



Are you missing anything?

Double-check all parts, hardware and accessories listed on Page 6 are accounted for.



Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!



Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!



Prep Time!

Please review the assembly instructions and all diagrams prior to assembling. Set up your workspace by laying the parts and hardware out separately, then begin!



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.




Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Save the instructions and store
any supplied tools for later
maintenance.



Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.



After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

CHAIR



X 2

PARTS

#1 1pc



Chair Back

#2 1pc



Left leg Set
(FL)

#3 1pc



Right leg Set
(FR)


#4 1pc



Center
Stretcher

HARDWARE

#A 6pcs




JCBC Bolt
M6 x 30mm

#B 2pcs



Barrel Nut
M6 x 10 x 13mm

#C 2pcs



JCBC Bolt
M6 x 45mm

#D 6pcs



Flat Washer
ø1/4" x 13mm

#E 6pcs



Spring Washer
ø1/4"

#F 1pc



Allen Key

#G 2pcs




Wood Button

ASSEMBLY INSTRUCTIONS


1

- Part **#2** x1pc
- Part **#3** x1pc
- Part **#4** x1pc
- Hardware **#B** x2pcs
- Hardware **#C** x2pcs
- Hardware **#G** x2pcs



2

- Part **#1** x1pc
- Hardware **#A** x6pcs
- Hardware **#D** x6pcs
- Hardware **#E** x6pcs



Align legs (#2,3) to the seat (#1), then secure by using bolts (#A) with washers (#E,D).

ASSEMBLY COMPLETED




Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Assembly Completed !!