

How to make moves with your Smart Switch:

- | | |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>1 Schedule your motion sensor to sleep when you sleep.</p> <p>Go to CYNC app and set the response schedule under room motion sensor.</p> | <p>2 Automate your lights by enabling ambient light and motion detection.</p> <p>Go to CYNC app and enable the ambient light sensor under room motion sensor.</p> |
| <p>3 Preset brightness levels.</p> <p>Dim switch to desired level, then turn off. Use Dim button instead of center on/off button to turn on lights at the preset level.</p> | <p>4 Control other CYNC bulbs in the room with your switch.</p> <p>Go to CYNC app. Add bulbs and switches to a room under create a room. (sold separately)</p> |

GE and C by GE are trademarks of General Electric Company. Used under trademark license.

PK-00100024-3

Connect to your Alexa or Hey Google device to control your lights with your voice.

Try these voice commands:

Amazon Alexa

Alexa, turn off the living room.

Alexa, good morning.

Alexa, set kitchen to 50%.

Hey Google

Hey Google, turn on the lights.

Hey Google, set bedroom to 20%.

Hey Google, I'm leaving.

Touch Controls & Sensors

