
ASSEMBLY INSTRUCTION

W2325P145175 W2325P144330 W2325P143935



Return &Warranty policy:

- -We strive to offer the highest quality products, and we also try our best to satisfy each and every customer that orders from us with replacement parts/or service as needed.
- -1.If the items is damaged or defective, please take photos as evidence for replacements and refunds.
- -Please do not return to store, contact the seller if you have any troubles with this product.
- -2.As the cushions are all vacuum compressed, there will be some wrinkles. Please give your cushions up to 72 hours to reach its original size and the wrinkles will basically disappear.
- -3. Please do not open the compressed packages until your sofa frame is completely assembled.


ASSEMBLY INSTRUCTION

HARDWARE LIST				
NO	DESCRIPTION	SKETCH	QTY	
1	PLASTIC GASKET		4 PCS	
2	SCREWS M8*60MM		4 PCS	
3	GASKET	0	4 PCS	
4	ALLEN KEY		1 PCS	

PARTS LIST				
NO	DESCRIPTION	SKETCH	QTY	
Α	LEG		4PCS	
В	BACK CUSHION		2PCS	
С	SEAT FRAME		1PC	
D	ARM		2PCS	
E	SEAT		1PC	
F	BACK REST		1PC	


Open the carton, and take out 2pcs back cushion and 1pc seat

В	2PCS
E	1PC




Take out 2pcs arm, 1pc seat frame, 4pcs screws M8X60MM,4pcs gasket, and 1pc allen key, connect arm and seat frame with screws.


D		2PCS
С		1PC
2		4PCS
3	0	4PCS
4		1PC




Install the leg(A) of the sofa and insert a plastic gasket(1) in the middle

Α	4PCS
1	4PCS







Folding cushion.

