
SASHA WOOD ACCENT TABLE

DESIGN# SFV2129

Assembly Instructions



Need help? Feel free to contact us via email or call if you have any specific questions!

contact us: cs@safavieh.com 866-422-9070



Thanks for bringing Safavieh Couture into your home

Everything we make is incredibly simple to set up, including your new end table. You won't need any additional tools.

Parts List A X 1 Table Top




B X 1 H Shaped Leg



C X 2 T Shaped Leg



Insert the pegs on the 2 "T" shaped legs (C) into the holes on the "H" shaped legs (B). Line up the screw holes on the crisscross metal plate (HW1) to the screw holes on the assembled legs. Use the Allen Key (HW4) to screw in 4 of the Hex Socket bolts (HW3) to attach the metal plate to the legs.



Hardware List

Anti-Tip Hardware

HW1 x 1
Crisscross Metal Plate 3.0*90*90mm

HW2 x 4
Metal Plate 3.0*25*80mm


HW3 x 16
Hex Socket Bolt 1/4"-20 x 0.625"

HW4x 1
Allen Key M4

HW5 x 1


2

Line up the screw holes on the metal plates (HW2) to the screw holes on the top of the assembled legs. Use the Allen Key (HW4) to screw in 4 of the Hex Socket bolts (HW3) into the center holes of the metal plates (HW2) to attach them to the legs.





Place the tabletop (A) upside down on a soft surface. Align the screw holes on the tabletop (A) to the screw holes on the metal plates (HW2). Use the Allen Key (HW4) to screw in the remaining 8 Hex Socket bolts (HW3) to attach the legs to the top as shown.



4

Turn the table upright. Place the accent table in the place where you will use it. Follow the installation instructions of the Anti-Tip Hardware (HW5) to attach the product to the wall. Adjust the levelers on the bottom of the legs as needed to make the table level. We'd love to see it - just tag us (we're @safavieh) and use the hashtag #safavieh on Instagram!

