

Built to Move. Made to Last.

The Desky COILFLEX™ Ergonomic Office Chair adjusts with you, not against you. Its wave-spring suspension and 3D mesh backrest balance comfort, breathability, and posture support through every movement. With 4D armrests, multi-function tilt, and precise seat depth control, our COILFLEX keeps you aligned, focused, and in flow all day long.




**4 Tilt Settings
(22° Recline)**



**Adjustable
Lumbar Support**



**4D Adjustable
Armrests**



**CoilFlex
Cushion System**













DESKY

COILFLEX™ ERGONOMIC OFFICE CHAIR




**ASSEMBLY
INSTRUCTIONS & FEATURES**

PARTS

A CHAIR BACK QTY 1 	E CHAIR BASE QTY 1 	I SPRING WASHER QTY 3 
B SEAT BASE QTY 1 	F CASTERS QTY 5 	K WASHER QTY 3 
C ARMRESTS QTY 2 (L+R) 	G M6 ALLEN KEY QTY 1 	L M8x30 SCREW QTY 4 
D GAS CYLINDER QTY 1 	H M8x25 SCREW QTY 3 	M DOUBLE BUTTON CONNECTOR QTY 2 


ASSEMBLY GUIDE

STEP 1




Insert the 5 casters into the chair base.

STEP 2




Insert the gas cylinder into the chair base, ensuring the thinner section faces away from the caster wheels.

STEP 3




Place the left and right armrests of the chair to the seat cushion mechanism respectively with a gasket M*1 and two screws L*2.

STEP 4



Position the seat cushion mechanism upside down. Align the backrest holes with the three holes on the mechanism and tighten using the three screws provided.

STEP 5



Insert the tip of the gas cylinder into the underside of the main body of the chair. Sit on the chair to firmly engage the cylinder.