

Single-Handle Lavatory Faucet Installation Instructions

INSTALLATION MANUAL Tools You will need





Adjustable Wrench


Philips Screwdriver

Before the Installation

- 1. Check the package and confirm all parts are included. If any part is missing or damaged, please contact us.
- 2.Do not disassemble the main body, as it has been installed & commissioned correctly & precisely before leaving the factory.
- 3. Shut off the main water supply prior to beginning installation.
- 4.Do flush the water supply lines to remove any dirt and debris before installation (IMPORTANT) .
- 5.Make sure to connect the hot/cold inlet pipe correctly. If standing in front, connect hot water pipe to the left and cold water pipe to the right.
- 6.After the installation, check for leaks and make sure every joint is safely sealed.


Cleaning and Maintenance


- 1. Rinse with clean water and dry with a soft cloth.
- 2.Do not use any detergent,acid,polisher,abrasives,or harsh cleaners.
- 3.Do not use cloth with a coarse surface.




Water outlet mode:

- 1 By default, the column is out of water;
- 2 Rotate the nozzle 90° counterclockwise to water the waterfall;
- 3 Rotate the nozzle 90° counterclockwise to water the rinse the mouth;
- 4 Rotate the nozzle 90° counterclockwise to water the rain waterfall







1. Hole:Ø35mm,Remove the rubber washer,metal washer and locking nut from the faucet.




2.Screw and hand tighten the hot and cold flexible hoses to the faucet. DO NOT use a wrench to tighten hoses as this may damage the hose and/or the hose threads.



3.Re-install the rubber washer followed by the metal washer and lock-nut. Hand tighten then tighten further using a screw driver to tighten lock-nut screws.



4. Attach flexible hose to water supply.



5.Finish