Step-By-Step Quick Start Guide To Using Your Generator



2 Add Oil

Oil Type: SAE10W-30 Oil (Must add BEFORE first use) Oil Capacity: 13.5 fluid oz

Because this generator includes Low Oil Shut Off, the generator will not start with low oil. Start out with 13.5 oz, then **FILL UNTIL ALMOST OVERFLOWING**.

Unleaded gasoline only octane rating of 87 or higher
Maximum Capacity: 1 Gallon fuel tank

4 Start The Generator

- Use the generator OUTDOORS in a WELL VENTILATED AREA.
- DO NOT CONNECT electrical devices until AFTER the generator is started.
- If using Propane LPG fuel, open fuel supply on the LP tank.
- If using gasoline, make sure unleaded gasoline fuel has been added to the tank.
- If using Propane LPG fuel, turn ENGINE SWITCH to ON position, and Petcock to OFF position.
- If using gasoline, turn ENGINE SWITCH to ON postion, and Petcock to ON position.
- Move Choke Lever to OUT/OFF position.
- Start the generator manually with the Recoil (Pull) Start.
- Once the engine has started, GRADUALLY push the choke lever to "IN/ON TO RUN" position. Let the engine run approximately 5 minutes BEFORE adding appliances or tools. You can now connect electrical devices.













TOLL-FREE NATIONWIDE HELP LINE! 866-460-9436



This generator includes a built-in Carbon Monoxide Warning Alert! The generator will automatically shut-off if dangerous levels of Carbon Monoxide is detected.

Need Help? Call Customer Service! Monday-Friday 8:00 AM - 4:00 PM Central Time



GEN2200DFI

2,200 Surge / 1,800 Running Watts*

POWERED BY UNLEADED ASOLINE OR PROPANE FUEL


- 3 HP Engine, 4 Stroke OHV
- 4650 RPM, 79.7CC
- Recoil Start
- 1 Gallon Fuel Tank
- Low Oil Shut Off
- UL Listed Electrical Components
- Engine Shut Off Switch
- 1 12V D/C Outlet
- 2 120V A/C Outlets
- Complies with EPA emissions
- Run time = 7 hours @ 50% load Gas
- Run time = 18 hours @ 50% load on 20 lbs of LPG Fuel
- Decibel Rating < 60 db @ 0% load measured at 23 feet
- * SURGE WATTS / RUNNING WATTS MAY BE REDUCED BY 10% WHEN USING PROPANE FUEL VS USING GASOLINE.
- DO NOT use E85, gas/oil mix, or modify the engine to run on alternate fuels.
- If you are using a generator 3,000 ft. above sea level, the generator may not function properly because of air flow getting through the carburetor.
- High Altitude Use: This generator is not recommended for high altitude use 3,000 ft. above sea level.
- Warranty: 2 YEAR Limited Emissions
- Warranty: 1 YEAR Limited

OIL IS NOT INCLUDED WITH THIS GENERATOR. IT IS SOLD SEPARATELY.

Read and understand instruction manual before using generator.

GEN2200DFI 2,200 Surge / 1,800 Running Watts

POWERED BY UNLEADED GASOLINE OR PROPANE FUEL



DO NOT CONNECT electrical devices until AFTER the generator is started.



IF THERE IS ANY QUESTION ABOUT A CONDITION BEING SAFE OR UNSAFE, DO NOT OPERATE THIS PRODUCT!

Always follow Warning labels placed on the generator, and read and follow all Warning labels included inside the Product Manual.

WARNING: NEVER use a generator inside a home or a garage, EVEN IF the doors and windows are open.

ONLY USE OUTSIDE and far away from windows, doors and vents leading into an enclosed area.

Using a generator indoors can kill you in minutes. The generator produces an exhaust that contains carbon monoxide. This is a poison you cannot see or smell.

Do not attach a chain or rope to secure the generator to a post as this can be difficult to remove in the event of an emergency.



This generator includes a built-in Carbon Monoxide Warning Alert! The generator will automatically shut-off if dangerous levels of Carbon Monoxide is detected.

AWARNING Carbon monoxide (also known as CO) can be dangerous for humans and pets. Carbon monoxide poisoning can lead to death in a very short time. It is called "the silent killer" because it is odorless, tasteless and invisible: you may be exposed without knowing it.

NOTE: The indicator will light RED and the engine will shutdown if dangerous Carbon Monoxide levels are detected. The engine will not restart for 5 minutes. If an error in the carbon monoxide system is detected, the indicator will blink YELLOW and the engine will shutdown for five minutes.



AUTOMATIC SHUTOFF - YOU MUST:

MOVE TO FRESH AIR AND GET MEDICAL HELP IF SICK, DIZZY OR WEAK. MOVE GENERATOR TO AN OPEN, OUTDOOR AREA. POINT EXHAUST AWAY. DON'T RUN GENERATOR IN ENCLOSED AREA (E.G. NOT IN HOUSE OR GARAGE).

READ MANUAL FOR COMPLETE CO WARNING INSTRUCTIONS!

TOLL-FREE NATIONWIDE HELP LINE! 866-460-9436

Need Help? Call Customer Service! Monday-Friday 8:00 AM - 4:00 PM Central Time

