

CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use.

Remove wooden furniture from standing water. Dust regularly with small brush or vacuum

Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

 **SAFAVIEH**
O U T D O O R

Weight Capacity : 40 lbs

Warning : Do not stand on table

Warning : Do not over torque bolts / screws




Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Balcony table		1X
B	Bolts	 M6x25	6X
C	Pass hang the balcony table		2X
D	Allen key	 LG4	1X

Model# PAT 7045

Product Dimensions: 27.55" W x 16.53" D x 13.85" H




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key


1



Step 1

Open the balcony table Vertical arrows

2



Step 2

Pull out support table and put them in clocks.


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key


3



Step3

Attach Pass hang the balcony table (C) to leg frame Balcony table (A).
Use Bolts (B) ,tighten with allen key (D)

4



Step 4

Balcony table is ready to be used