

LED RECHARGEABLE CANDLES WITH REMOTE CONTROL

7503R3



⚠ WARNING

THIS PRODUCT CONTAINS A BUTTON BATTERY

- DEATH or serious injury can occur if ingested.
- A swallowed button or coin battery can cause internal chemical burns in as little as 2 hours.

V1 User Manual

LED RECHARGEABLE CANDLES WITH REMOTE CONTROL

This USB rechargeable candle set is only to be used indoors. This LED candle set is not a toy and should be kept out of reach of children. USB input DC 5V <400mAh, Li-ion battery 450mAh, 1.665Wh (included), charge time 0.9–1.5 hours, discharge time 55–100 hours.

This LED candle set has 5 functions that are used by remote control:

1. ON (Green button on remote control)
2. OFF (Red button on remote control)
3. TIMER for automatic ON and OFF:
2H on/22H off 4H on/20H off
6H on/18H off 8H on/16H off
4. MODE for Candle or Light
5. DIM for Increasing or Decreasing the brightness

NOTE:


The timer will be set to 2, 4, 6 or 8 hours (which depends on the selection by remote) automatically and then switch OFF the light. The light will then stay OFF for 22, 20, 18 or 16 hours (depends on the selection by remote) and start again automatically for the selected hours the next day at the same time it was started. Remark: The timer works for 24H a day, if the power is interrupted or batteries are replaced, the timer settings are lost and should be set again.

Remote control instructions:

1. Infrared remote control size: 86*40*6.0mm
2. CR2025 3V battery for remote control, positive side facing up. Please delete the insulation plastic before using it!
3. Remote controllable distance is around 5–10 meters.
4. Remote control function: ON and OFF, 4x Timers, Candle or Light mode and dimmable buttons

USB rechargeable instructions:

Indicator light: red light on when charging,
red light off when fully charged



NOTE:

For the best results, you need to charge the candle set when the brightness of the light candle decreases and /or when the light candle stops working, or if remote control does not work anymore.

Correct Disposal Of This Product



(Waste Electrical & Electronic Equipment)

This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household user should contact either the retailer where they purchased this product or their local government office for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

Disclaimer

Information in this document is subject to change without notice. The manufacturer does not make any representations or warranties (implied or otherwise) regarding the accuracy and completeness of this document and shall in no event be liable for any loss of profit or any commercial damage, including but not limited to special, incidental, consequential or other damage. No part of this document may be reproduced or transmitted in any form by any means, electronic or mechanical, including photocopying, recording or information recording and retrieval systems without the expressed written permission of the manufacturer.

For installation, please refer to the written instructions.

Need to contact us?

Please send an email at: service@aloadecor.com

Need more information?

Please visit our website: www.aloadecor.com