# Outdoor Chaise Lounger and a

## N715P241220; N715P241221

Please read all instructions carefully:

- 1. Have 2 adults on hand for assembly.
- 2. 50% Tighten before fixing all screws, Allen wrench is
- 3. Place the item on a flat ground to adjust and make sure it remains stable.
- 4. Tighten up all screws with tools gradually.
- 5. If the screws are not aligned with holes during assembly, please loosen all the other screws to 50% and continue the assembly process.
- 6. If the item is not stable, please loosen all the screws, adjust it on a flat ground and tighten up all screws again.
- 7. Note : If one or some screws are fully tightened during assembly, chances are the others will not be aligned with holes. In addition, all the holes are designed to be relatively larger to provide more space for the adjustment of the screws.

# Assembly Instruction

### Caution: You must read these Assembly Instructions before you proceed.































# **FINISH**