




ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



Screwdriver
(Not included)



(Included)
Allen Wrench



2 - People

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

☐

Are you missing anything?

Double-check all parts, hardware and accessories listed are all accounted for.

☐

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!

☐

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling.


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.



Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.



Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Save the instructions and store
any supplied tools for later
maintenance.


Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.




After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

DINING CHAIR (2PCS/CTN)




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS


1



CHAIR BACK

1 pc x 2.


2



SEAT

1 pc x 2.

3



RIGHT LEG

1 pc x 2.

4



LEFT LEG

1 pc x 2.

5



RIGHT STRETCHER

1 pc x 2.

6



LEFT STRETCHER

1 pc x 2.

HARDWARE

A



Bolt Ø5/16" x 3"

4 pcs x 2.

B



Bolt Ø5/16" x 2 3/16"

4 pcs x 2.

C



Bolt Ø5/16" x 1 1/2"

2 pcs x 2.

D



Lock Washer Ø5/16"

10 pcs x 2.


E



Flat Washer Ø5/16"

10 pcs x 2.


F



Wood Screw (Ø4* 1 1/2")

4 pcs x 2.



G



Allen Wrench M4

1 pc x 2

packed in 1 cases

Carton	Designation	Part		Hardware
	Chair Back	①		 ④ A 4pcs  ④ B 4pcs
	Seat	②		 ② C 2pcs  ⑩ D 10pcs
	Right Leg	③		 ⑩ E 10pcs  ④ F 4pcs
	Left Leg	④		 ① G 1pc
	Right Stretcher	⑤		
	Left Stretcher	⑥		



ASSEMBLY INSTRUCTIONS

1

Part ① x 1pc
 Part ② x 1pc
 Hardware ① x 4pcs
 Hardware ② x 2pcs
 Hardware ③ x 6pcs
 Hardware ④ x 6pcs
 Hardware ⑤ x 1pc


1. Prepare 4 bolt assemblies by first inserting a lock washer (D) onto the bolt (A) then a flat washer (E) onto that same bolt (A) .

Prepare 2 bolt assemblies by first inserting a lock washer (D) onto the bolt (C) then a flat washer (E) onto that same bolt (C) .



3. Assemble the seat and the back chair by bolt (A) with washer (D),(E) using Allen wrench (G)
 * Do not tighten the bolts

2. Align wooden dowel of the seat (2) to the back chair (1), then assemble the seat and the back chair by bolt (C) with washer (D),(E) using Allen wrench (G).
 * Do not tighten the bolts





2

Part ③ x 1pc
 Part ④ x 1pc
 Hardware ⑥ x 4pcs
 Hardware ③ x 4pcs
 Hardware ④ x 4pcs
 Hardware ⑤ x 1pc

1. Prepare 4 bolt assemblies by first inserting a lock washer (D) onto the bolt (B) then a flat washer (E) onto that same bolt (B) .

2. Align front legs (3), (4) to the seat (2), then assemble the seat and the legs by bolt (B) with washer (D),(E) using Allen wrench (G).
 * Do not tighten the bolts



ASSEMBLY INSTRUCTIONS


3

Part ⑤ x 1pc

Part ⑥ x 1pc


Hardware ⑦ x 4pcs

1. Prepare 4 screw (F)
2. Place right, left stretcher (5), (6) to middle the back legs and front leg, then assemble the stretchers and the legs by screw (F) using screwdriver.
* Do not tighten the screw



4

To level the chair, stand the chair up on a flat surface and tighten all the bolts by using Allen Wrench (G) and tighten all the screws by using a screwdriver.



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.



This product is intended for RESIDENTIAL USE ONLY and not for commercial use.

ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED



Allen Wrench



2 - People

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

☐

Are you missing anything?

Double-check all parts, hardware and accessories listed are all accounted for.

☐

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!


☐

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling.



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.



Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Save the instructions and store
any supplied tools for later
maintenance.



Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.



After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

DINING TABLE



PARTS


1



TOP TABLE

1 pc.

2



MIDDLE TOP TABLE

1 pc.


3



MOUTING PLATE

2 pcs.

4



LEG

2 pcs.

5



CROSSBAR

1 pc.

6



BASE

2 pcs.

HARDWARE

A



Bolt Ø5/16" x 2"

22 pcs.

B



Lock Washer Ø5/16"

22 pcs

C



Flat Washer Ø5/16"

22 pcs


D



Allen Wrench M4

1 pc

packed in 1 cases

Carton	Designation	Part		Hardware
	Top Table	①		 ① 22pcs  ② 22pcs  ③ 22pcs  ④ 1pc
	Middle Top Table	②		
	Mounting Plate	③		
	Legs	④		
	Crossbar	⑤		
	Base	⑥		


ASSEMBLY INSTRUCTIONS

1

Part ③ x 2pcs
 Part ④ x 2pcs
 Hardware ① x 4pcs
 Hardware ② x 4pcs
 Hardware ③ x 4pcs
 Hardware ④ x 1pc

1. Prepare 4 bolt assemblies by first inserting a lock washer (B) onto the bolt (A) then a flat washer (C) onto that same bolt (A) .

2. Align 2 wooden dowel of legs (4) to the mounting plate (3), then assemble the mounting plate and the legs by bolt (A) with washer (B),(C) using Allen wrench (D)





2

Part ⑥ x 2pcs
 Hardware ① x 6pcs
 Hardware ② x 6pcs
 Hardware ③ x 6pcs
 Hardware ④ x 1pc

1. Prepare 6 bolt assemblies by first inserting a lock washer (B) onto the bolt (A) then a flat washer (C) onto that same bolt (A) .

2. Align 2 wooden dowel of legs (4) to the base (6), then assemble the base and the legs by bolt (A) with washer (B),(C) using Allen wrench (D)




ASSEMBLY INSTRUCTIONS

3

Part ③ x 1pc
 Hardware ① x 4pcs
 Hardware ② x 4pcs
 Hardware ③ x 4pcs
 Hardware ④ x 1pc

1. Prepare the crossbar on the middle two the legs frame, then assemble the crossbar and the legs frame by bolt (A) with washer (B),(C) using Allen wrench (D)


1. Prepare 4 bolt assemblies by first inserting a lock washer (B) onto the bolt (A) then a flat washer (C) onto that same bolt (A) .



4

Part ① x 1pc
 Hardware ① x 8pcs
 Hardware ② x 8pcs
 Hardware ③ x 8pcs
 Hardware ④ x 1pc


1. Prepare 4 bolt assemblies by first inserting a lock washer (B) onto the bolt (A) then a flat washer (C) onto that same bolt (A) .
 2. Place the top table (1) face down onto a protected surface
 3. Place the leg frame on the top table (1). Align the mounting plate of legs with the top table.
 4. Assemble the mounting plate and the top table by bolt (A) with washer (B),(C) using Allen wrench (D)



ASSEMBLY INSTRUCTIONS

5


Open and lock the top table by the lock located below the table top



6

Part ② x 1pc


Open the top table, pull it out to both sides, then place the leaf of table top (2) on the table





ASSEMBLY INSTRUCTIONS

7


Open and lock the top table by the lock located below the table top



Place the table on a flat surface and twist the levelers on the bottom of the table legs



8



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use.