






USE AND CARE MANUAL

TABLE LAMP
Model number: 21387



Hardware (Parts are not to scale)

H1 Finial (Pre-assembled to harp (H2)) 1 pc	H2 Harp 1 pc	H3 5 W LED bulb 1 pc	H4 Square ring 1 pc
			

**THIS MANUAL CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND
KEEP FOR FUTURE REFERENCE.**

IMPORTANT SAFETY INFORMATION

- This lamp is for indoor use only. The lamp should not be used near water. Never immerse the lamp in water or other liquids.
 - Never cover the lamp with any object including cloth or paper as this is a fire hazard.
 - Do not handle the bulb immediately after the light is turned off as it will be hot.
 - This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.
-


PREPARATION

- Before beginning assembly, installation or operation of product, make sure all parts are present. Compare parts with package contents list and diagram on previous page. If any part is missing or damaged, do not attempt to assemble, install or operate the product. Contact customer service for replacement parts.
-

ASSEMBLY


1 Assembling the glass shade

- Put the small hole of the glass shade (C) through the socket of the fixture body (B). Make sure to fully secure the glass shade (C) in place by turning the shade clockwise until it is locked in place and can not longer be rotated. Do not over tighten to avoid damaging glass shade (C).



2 Assembling the square ring


- Put the square ring (H4) through the socket of the fixture body (B).
- Tighten the square ring (H4) onto the socket of the fixture body (B).
- Adjust the square ring (H4) parallel to the fixture body (B).



ASSEMBLY (continued)

3 Assembling the harp


- Insert the harp (H2) prongs into the saddle of the fixture body (B) and slide the retaining covers over joints to secure the harp.



4 Installing the light bulbs

- Install the light bulb (no included) into the socket of top of the fixture body (B). Use one **Max 16W medium base (E26) self-ballasted LED bulb** (recommended).
- Install the night light bulb (H3) into the socket of bottom of the fixture body (B). Use one **Max 9W candelabra base (E12) self-ballasted LED bulb** (recommended).


NOTE: You can also use one **MAX 100W medium base (E26) type "A"** bulb for upper light, and use one **Max 40W candelabra base (E12) type "B"** bulb for night light. Do not exceed the recommended wattage.



5 Assembling the shade

- Unscrew the finial (H1) from the harp (H2).
- Place the shade (A) onto the harp (H2) and secure with the finial (H1).

NOTE: Remove the plastic cover from the shade before using.




ASSEMBLY (continued)

6 Using the table lamp

- Plug into the wall outlet, turn on the switch and enjoy. This table lamp has 4 options:
 - **The night light ON**
 - **The upper light ON**
 - **Both night light and upper light ON**
 - **Off**

NOTE: Grasp the finial (H1) to adjust the shade (A) to level if shade (A) is skewed.



CLEANING

- Do not use any cleaners with chemicals, solvents, or harsh abrasives. Use only a dry, soft cloth to dust or wipe carefully.
- To clean the fixture, pull the plug from the wall outlet. Use a dry or slightly dampened, clean cloth to wipe the exterior surface of the fixture.

TROUBLESHOOTING

- The light does not come on at all:
 - a) Ensure whether the bulb is burned out.
 - b) Ensure the power supply is turned on.
 - c) Ensure the cord is plugged into an outlet.
 - d) Ensure the circuit breaker is set in the "ON" position.
- Fuse blows or circuit trips when light is turned on.
 - a) Check for crossed wires, ensure wiring is correct.