



# Instruction Manual

## Table Lamp Set Of 2



## Overview



## Assembly Instruction

1. Pull out the Power cord A gently until bottom of Socket assembly C reaches the top of Lamp base B.
2. Rotate Socket assembly C counter-clockwise by two turns, then screw Socket assembly onto Lamp base B and tighten.
3. Insert Harp F into Saddle D.
4. Install E26 bulb E into socket.
5. Attach assembled Lamp shade G onto Harp F and tighten it with Finial H.

**For Lamp shade assembly, please refer to attached instruction-Lamp Shade Assembly.**

## Product Specifications

Input voltage	120V
Rated power	100W MAX
Lamp socket	E26
Cord Length	5ft.

## Product Packaging

Lamp base assembly	× 2
Lamp shade cloth	× 2
Shade frame	× 4
Harp&Finial	× 2
E26 bulb	× 2
Lamp manual	× 1
Lamp shade manual	× 1

## Safety Warning:

### BULB TYPE:


Use only the bulb type and wattage indicated on Wattage Label placed on or near socket.

**WARNING: NEVER EXCEED MAXIMUM WATTAGE Indicated as bulb may cause fire.**

### CAUTION:

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature. This plug can be used in a polarized outlet only one way. If plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician.

**DO NOT ALTER THE PLUG!**



### PROPER LAMP CARE:

Use a soft cloth to dust your lamp on a regular basis. Never use chemicals or an abrasive cleaner, to do so may damage the finish on your lamp.

### TROUBLESHOOTING:

If fixture does not work:

1. Turn off electrical power and check all wire connections.
2. Check fuse or circuit breaker and replace if necessary.
3. Check to make sure light bulb is in working order.

### CONTACT US

E-mail: [service@24h-reply.com](mailto:service@24h-reply.com)