




7



8



Ref#	Part Number	Description	Qty	Ref#	Part Number	Description	Qty
1	YTL-694-312-01	Handle	1	6	YTL-694-312-06	Lock	1
2	YTL-694-312-02	Dump Frame	1	7	YTL-694-312-07	Brace	2
3	YTL-694-312-03	Front Axle	1	8	YTL-694-312-08	Rear Axle	1
4	YTL-694-312-04	Tub	1	9	YTL-694-312-09	Hardware kit	1
5	YTL-694-312-05	Tire	4	10	YTL-694-312-10	Plastic Cap	1

Limited Warranty

Warranty

For one year from the date of purchase YTL International will replace for the original purchaser, or repair the utility dump cart. The warranty will not apply to any unit that was not assembled correctly, misused, overloaded or which has been used or operated contrary to our instructions, or the unit has been repaired or altered by anyone other than an authorized representative.

Warranty Exclusions

This warranty does not cover cosmetic defects such as paint, decals or wear items such as tires. This warranty will not cover failures or problems due to acts of God, or events or forces beyond the control of the manufacturer.

Normal Wear Exclusion

The poly cart needs periodic service to perform well. This warranty does not cover repair when normal use has exhausted the life of a part or the equipment as a whole.

Installation, Use and Maintenance Exclusion

This warranty will not apply to parts and/or labor if the utility dump cart has been misused, neglected, involved in an accident, abused, loaded beyond its limits, modified or assembled incorrectly. Normal maintenance is not covered under this warranty.

YTL International disclaims any obligation to cover any loss of time, use of this product, freight, or any incidental or consequential claim by anyone from using this poly cart. THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR.

An exchange unit will be subject to the original warranty. The length of the warranty governing the exchanged unit will have the date as the purchase date of the original unit. This warranty gives you certain legal rights which may change from state to state. Your state may also have other rights you may be entitled to that are not listed within this warranty.

Contact Information

YTL International Inc.
13365 Estelle Street,
Corona, CA 92879
Phone: (888)723-6534
Phone: (562)404-8016
Fax: (562)404-8013
Email: parts@ytlinternational.com


YARD COMMANDER

1000lb Poly Garden Cart 6 CU FT



1000LB Poly Cart
Scan QR code with your phone's camera to access testimonials, manuals, in use videos, maintenance guides and view related items.

SCAN ME



YTL-694-312

IMPORTANT SAFETY INSTRUCTIONS

1. Read, understand and follow ALL instructions before using this product.
2. Do not exceed the overall maximum load capacity of 1,000 lbs. or the maximum dumping load capacity of 500 lbs. The weight rating is based on an evenly distributed load.
3. Do not allow children to use the cart without supervision. This cart is not a toy.
4. Do not use this cart for transporting passengers.
5. This cart is not intended for highway use.
6. Do not exceed 5 mph.
7. Distribute the load evenly over the surface of the tray.
8. Do not load items on the top edges of the tray.
9. If any parts become damaged, broken or misplaced, do not use the cart until replacement parts have been obtained.
10. It is recommended that the cart be inspected for damage before each use.
11. Do NOT inflate pneumatic tires above the maximum tire pressure of 30 PSI (2.07 BAR).
12. KEEP THESE INSTRUCTIONS FOR FURTHER REFERENCE.

HARDWARE

STEP 1

STEP 2


STEP 3

STEP 4

STEP 5

STEP 6

TOOLS REQUIRED



ASSEMBLY INSTRUCTIONS

1

x2
M8 × 50 Bolt

x2
M8 × 25 Bolt

x4
φ 8 Washer

x4
φ 12 Washer

x4
M8 Lock Nut

2

x2
M8 × 25 Bolt

x2
M8 × 22 Bolt

x2
φ 12 Washer

x4
φ 8 Washer

x2
M8 Lock Nut

3

x4
M8 × 55 Bolt

x4
φ 8 Washer

x4
M8 Lock Nut

4

x1
φ 16 Plastic Washer

x1
φ 16 Washer

x1
M16 Lock Nut

5

x2
Spacer

x4
φ 16 Washer

x4
Cotter Pin Φ3×40

6

x1
M8 × 60 Bolt

x1
φ 8 Washer

x1
M8 Lock Nut