
# **ASSEMBLY INSTRUCTION**

### **7 PCS PATIO DINING SET**



## WF322818, WF322819

#### Notice:

- 1. 50% Tighten before fixing all screws, Allen wrench is recommended instead of an electric drill.
- 2. Place the item on a flat ground to adjust and make sure it remains stable.
- 3. Tighten up all screws with tools gradually.4. If the screws are not aligned with holes during assembly, please loosen all the other screws to 50% and continue the assembly process.
- 5. If the item is not stable, please loosen all the screws, adjust it on a flat ground and tighten up all screws again.
- 6. Note: If one or some screws are fully tightened during assembly, chances are the others will not be aligned with holes. In addition, all the holes are designed to be relatively larger to provide more space for the adjustment of the screws.

1. Thank you for choosing our products.

#### 2. Return Policy



DO NOT RETURN TO THE STORE! Skip the process of returning your product and contact us directly for a replacement

If you find that parts of your order are missing or damaged, we will gladly ship any needed replacement parts free of charge.

If your product's quality does not meet your expecta?ons or you have found any sort of defect, please contact our customer service department and let us know the details of your order and any issues encountered, we will try our best to provide you with a solu?on. Feel free to also directly contact our manufacturer concerning needed replacement parts and they will be happy to help provide you with a solu?on or answer any quess?ons you may have.

Recommenda?o s Before Beginning Assembly

- Read instructons, cover to cover
- ♦ Have 2-4 adults on hand for assembly depending on product size
- Do not assemble directly on flooring or carpet
- Assemble on a clean non-marring surface (example: packing foam)
- Save all packaging untl finished

#### 3. Assembly No?ce:

• If you encounter any problems during assembly and find that you cannot coonnue, rest assured we will help you solve the situation as soon as possible. Simply keep all of the


- parts of the product stored in a safe place and contact us immediately so we may assist you further.
- Once you have opened your package, remove all inner hardware packages and take the
  parts out. One by one, Place the parts out neatly in front of you, then refer to the
  instruc?ons to ensure no parts are missing. If any pieces are found missing, please
  carefully look in the box first, as the hardware packaging might have torn making the
  hardware spill in the box.
- Some key parts of your product may be stored and hidden inside of other parts. Please open any zippered or hook & loop storage compartments to remove all parts. (example: cushions and legs being stored in the underside of a sofa)
- IMPORTANT: When se?ng up your product, DO NOT INSTALL THE SCREWS ALL THE WAY
  IN THE BEGINNING. Place each screw into their proper hole and use your hand to twist
  the screw halfway. Twist all the screws in halfway to ensure the holes will match up
  properly and the product is level on the ground. When everything seems fi?ed , then
  ?ghten the screws.
- When you have completed assembly, we suggest you have more than one person to assist you with lifting and placing the product.


#### Care & Maintenance


- O Do not put hot items directly on furniture surface
- Do not clean furniture with harsh cleansers or polish
- Do not place furniture near heating or cooling vents
- Do not write on furniture without a padded barrier to protect the surface
- Not for commercial use. For residen? I use only
- Stains may be removed with mild soap soluton and damp cloth
- Children should not climb or jump on the furniture
- Dust and pick-up spills using a clean, non-colored, lint-free cloth

#### Cau?on

- This product contains small components. Please ensure that they are kept away from small children.
- Do not use power tools to assemble your furniture. Power tools may strip or damage the parts.







### **Hardware** 1 2 3 4 $\Theta$ (0) (0) θ M6 x 20mm M6 x 35mm M6 x 40mm M6 x 55mm (36 pcs) (12 pcs) (24 pcs) (66 pcs) 5 7 6 8 (<del>0</del>) M6 x 100mm Washer Plastic Washer 5mm **Plastic Washer 15mm** (156 pcs) (15 pcs) (24 pcs) (12 pcs) 9 10 11 12 0 0 **Part I-Short** Nuts **Allenkey Plastic Washer 30mm** (2 pcs) (2 pcs) (27 pcs) (12 pcs) 13 Wrench (1 pc)

