# **AIR PURIFIER**

## **USER MANUAL**



TRUE HEPA FILTER




3 - STAGE FILTRATION SYSTEM



LOW NOISE LEVEL



HIGH CLEAN AIR DELIVERY RATE



Model: EPI153

## **CUSTOMER SERVICE**

Our customer service team is standing by to assist you if you have any questions or concerns.

- www.mookashops.com
- support@mookashops.com
- 1-855-666-9955
- m.me/MookaOnlineShop

## **CONTENT**

IMPORTANT ·····	01
CONTROL PANEL OVERVIEW	03
HOW TO USE ·	04
PRODUCT FEATURES ······	06
PRODUCT OVERVIEW ·····	07
MAINTENANCE & REPAIR ······	08
FAQ	09
SAFETY PRECAUTIONS ·	10

#### **READ AND SAVE THESE INSTRUCTIONS**

#### 1 IMPORTANT

This appliance has a polarized plug (one blade is wider than another). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet one way only.

If the plug does not fit fully into an outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature

To reduce the risk of fire or electric shock, do not use this appliance with any solid-state speed control device.

#### **BEFORE USE**

Check if the voltage indicated on the appliance corresponds to the local power voltage before you connect the appliance. Other electric appliances used simultaneously may cause the socket to be hot or cause the fire.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard.

Make sure the power cord is plugged firmly and securely into the outlet.

Please switch off and unplug the appliance (pull the plug itself, not the lead) when cleaning or when it is not in use for a long time. Do not forget to remove the attached accessories.

#### **SAFETY TIPS**

Keep the appliance away from flammable gases and liquids, candles and open flames.

Do not use the appliance in wet, moist areas such as bathrooms, steamy kitchens, or near swimming pools, otherwise, it may cause an electric shock.

Do not spray water or other liquids in an area where an appliance is operating.

Adding essential oils to the air purifier could cause malfunction.

Operating temp range: 32-104°F (0-40°C).

#### **CLEANING AND MAINTENANCE**

Never use abrasive objects which could damage your appliance's appearance.


Clean the appliance with a soft, dry cloth.


Never use abrasive cleaning agents, scourers, acetone or petrol to clean the appliance.

Switch off the appliance and unplug it from the wall outlet before cleaning.

Never immerse the motor base in water or place it under running water to avoid the risk of electric shock

## **3 CONTROL PANEL OVERVIEW**





	Power on/off. When the purifier is switched on, the filtration speed level 2 is always set automatically.
2	Press the " $\textcircled{\&}$ " button repeatedly to set the required fan speed level (2 $\rightarrow$ 3 $\rightarrow$ S $\rightarrow$ 1 $\rightarrow$ 2).
	Press the " ( ) " button to pick the required operating time (1, 2, 4, or 8 hours).
	Filter reset

#### HOW TO USE 4

#### 1. STANDBY

Please insert the plug into the power socket firmly, all the indicators light up. Air purifier enters standby mode by default in 3 sec. The power button half dimmed.

## 2. "POWER" ON/OFF

Press the " (1) " button to switch on the unit. When the purifier is switched on, the filtration speed level 2 is always set automatically.

Press the "  $\binom{1}{2}$ " button again to switch off the unit.

### **3. "SPEED"** (

Press the "  $\bigcirc$  " button repeatedly to choose between the available fan speed levels. Remember that the initial speed level is 2, thus the fan speed cycle setting is as follows:  $2 \rightarrow 3 \rightarrow S \rightarrow 1 \rightarrow 2$  (S – Sleep Mode, refer to "Sleep Mode" section).

Press and hold the " D " button for 3 seconds to turn the night light off.

Press any key to turn the night light on.

#### **HOW TO USE**

## 4. "TIMER"

Use the timer function to set the appliance operating duration.

Press the "  $\bigcirc$  " button to pick the required operating time (1, 2, 4, or 8 hours).

Air purifier shuts off automatically at the end of the selected period.

#### 5. "FILTER RESET"



Once air purifier is powered on, filter lifetime counter will count down, "Filter Reset" function is designed for 2,000 hours. Once the time is accumulated to 2,000 hours, "Filter Reset" button will flash.

After the filter replacement, press the "Filter Reset" button to reset the filter lifetime counter.

#### 6. SLEEP MODE

Press the "  $(\mathcal{A})$  " button repeatedly to set sleep mode.


All buttons' light — except the sleep mode indicator and power button — will be switched off. Sleep mode indicator and power button are half dimmed.

The air purifier filtration speed is adjusted to the lowest airflow speed. Press any button to quit sleep mode.


### PRODUCT FEATURES 6

- 1. Pre-filter, HEPA with carbon coating filter
- 2. Four timer settings
- 3. Three speed levels, sleep mode
- 4. Filter lifetime counter


#### **AIR PURIFIER STRUCTURE**



## 7 PRODUCT OVERVIEW



#### **MAINTENANCE & REPAIR 8**



- ◆ Rotate the base cover counterclockwise until the " ▲ "symbol and power cord are aligned, take the filter out and replace it with the new one.
- ◆ Place the lid so that " ▲ " mark is aligned with the power cord. Rotate the lid clockwise until power cord and " | " symbol are aligned.

## 9 FAQ

PROBLEM	POSSIBLE CAUSE	SOLUTION
The product doesn't work.	The rated voltage doesn't correspond to the local power voltage.	Check if the voltage indicated on the appliance corresponds to the local power voltage.
Odor can't be removed	Filter lifetime is over.	Clean the filter or replace with the new one.

#### **SPECIFICATIONS:**

◆ Rated voltage: AC 120V

◆ Rated power: 45W

◆ Dimensions: 210X210X314 mm

♦ Unit weight: 2.15 KG

#### **SAFETY PRECAUTIONS 10**

Please carefully read this instruction manual before using the product for the first time

- Check if the voltage indicated on the appliance corresponds to the local power voltage before you connect the appliance.
- Switch off and unplug the appliance (pull the plug itself, not the lead) if you
  are cleaning the appliance or when it is not being used for a long time.
- Do not block the air inlet and outlet.
- Ensure that foreign objects do not fall into the appliance through the air outlet.
- $\bullet$  The unit is intended for indoor use only.
- Dismantling should be performed by a qualified technician only.

## mooka

- www.mookashops.com
- ✓ support@mookashops.com
- **\(\sigma\)** 1-855-666-9955
- m.me/MookaOnlineShop



Made in China