


TOOLS REQUIRED



Allen Wrench



Screwdriver

(Not Included)




2 - People Recommended

ASSEMBLY RATING



EASY → DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



	Are you missing anything?		Check out our Quick Tips!
	Double-check all parts, hardware and accessories listed are all acccounted for.		We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
	Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!		Prep Time!
			Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.






Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

RECT.COCKTAIL TABLE



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS





TABLE TOP 1 pc.





LEGS 4pcs





BOTTOM 1pc

HARDWARE

















ALLEN WRENCH M4 1pc.


BOLT **Ø** 5/16" x 2" 8 pcs.

LOCK WASHER Ø 5/16" 8pcs.

FLAT WASHER Ø 5/16*19mm 8pcs.

1

Part #1 x 1pc
Part #2 x 3pcs
Hardware # A x1pc
Hardware # B x 3pcs
Hardware # C x 3pcs
Hardware # D x 3pcs





Attach the Legs (#2) to the Table Top(#1) as shown below .Using Bolt (#B) Lock washer (#C), Flat washer (#D) and Allen Wrench (#A)

2

Part #1 x 1pc
Part #2 x 1pc
Part #3 x 1pc
Hardware # A x1pc
Hardware # B x 5pcs
Hardware # C x 5pcs
Hardware # D x 5pcs

Attach the bottom shelf (#3)to the leg (#2) and attach 4th leg to table top and bottom shelf .Using Bolt (#B) Lock washer (#C), Flat washer (#D) and Allen Wrench (#A).





ASSEMBLY COMPLETED




Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.



TOOLS REQUIRED




Phillips Screwdriver

(Not Included)



2 - People Recommended

ASSEMBLY RATING




The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



Are you missing anything?	Check out our Quick Tips!
Double-check all parts, hardware and accessories listed are all acccounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time!
	Please review the assembly instructions and all diagrams prior to assembling.
The second secon	

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE



FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

END TABLE



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.





PARTS














TABLE TOP 1pc LEGS 4pcs BOTTOM 1pc

HARDWARE


















ALLEN WRENCH M4 1pc. BOLT Ø 5/16" x 2" 12 pcs. LOCK WASHER Ø5/16"
12pcs.

FLAT WASHER Ø5/16*19mm 12pcs.


1 Part # 1 x 1pc

2



Part #1 x 1pc
Part #2 x 4pcs
Hardware #Ax 1pc.
Hardware #Bx 6pcs.
Hardware #Cx 6pcs.
Hardware #Dx 6pcs.

Remove drawer from case as shown





Attach the Legs (#2) to the Table Top(#1) as shown below .Using Bolt (#B) Lock washer (#C), Flat washer (#D) and Allen Wrench (#A)

3

Part #1 x 1pc
Part #2 x 1pc
Part #3 x 1pc
Hardware #Ax 1pc.
Hardware #Bx 6pcs.
Hardware #Cx 6pcs.
Hardware #Dx 6pcs.

Attach the bottom shelf (#3)to the leg (#2) and attach 4th leg to table top and bottom shelf .Using Bolt (#B) Lock washer (#C), Flat washer (#D) and Allen Wrench (#A). Put the drawer on case.





Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.

manual and any order-related information for future reference.