


Place the Seat (A) on the ground, as shown in picture above.


Attach the Base (C) to the Seat (A) using Bolts (@) with Washers (@) with Allen Wrench (@) as shown in the picture above.

Do not fully tighten the bolts.

Step 2



Put the Cushion (C) onto the Seat (A). Then tie the rope on the Cushion (C) to the seat (A).



This Chair can only be used on a flat, level surface.

Care & Maintenance

	Prolonged exposure to rain may cause rusting which can stain floors.
	Do not put hot items directly on furniture surface.
Onewer	Do not clean furniture with harsh cleansers or polish.
Ö	To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
¥/	Children should not climb or jump on the furniture.
L	Do not write on furniture without a padded barrier to protect the surface.
<u></u>	To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
	Not for commercial use. For residential use only.
MLD.	Stains may be removed with mild soap solution and damp cloth.
	Keep away from sources of ignition.
	Dust and pick-up spills using a clean, non-colored, lint- free cloth.