







WF186907KAA



WF186907KAA


P. 2








Part.	Item.	QTY.	
A	M5X45	56	
B		56	
C	M3. 5X14	36	
D	M4X18	4	
E	M5X40	4	
F	M4X96	2	
G			




5X45mm bolt installation as below







1






2





3






4




5





Disconnect the keyboard rail with the BLACK PLASTIC PART. It needs to be pulled down to disconnect the runners.




6




. SCREWS





7




. SCREWS



. SCREWS



8




. SCREWS

B



8


PCS



1

2

9



. SCREWS

A



2

PCS



. SCREWS

C



2





PCS



Pull out


Push

Disconnect the keyboard rail with the BLACK PLASTIC PART. It needs to be pulled down to disconnect the runners.




10

. SCREWS
A M5X45
2 PCS




11

. SCREWS
B 4 PCS





12

. SCREWS
A M5X45
4 PCS




13

. SCREWS
B 4 PCS




14



. SCREWS


A M5X45
10 PCS

15




. SCREWS

B 8 PCS




16




. SCREWS

A M5X45
2 PCS




17




. SCREWS

B 2 PCS



18




. SCREWS

B




2

PCS



19




. SCREWS

B




6

PCS



20



. SCREWS


A



M5X45

6

PCS




21

. SCREWS

B



6 PCS



22

. SCREWS

C


M3. 5X14




4 PCS



Pull out



Disconnect the keyboard rail with the BLACK PLASTIC PART. It needs to be pulled down to disconnect the runners.



23

. SCREWS

C


M3. 5X14




4 PCS




Pull out




Disconnect the keyboard rail with the BLACK PLASTIC PART. It needs to be pulled down to disconnect the runners.




24




25



. SCREWS		. SCREWS	
A	M5X45	B	
	4 PCS		4 PCS




26




27

. SCREWS	
E	M5X40
	4 PCS




28

. SCREWS		. SCREWS	
D	M4X18	F	
	2 PCS		1 PCS




29

. SCREWS	
C	M3. 5X14
	4 PCS



30



31

