
support@ihomeangel.com



Item Number: A03320

WARNING (To reduce the risk of fire, electric shock, or injury to persons):


- We suggest installation by a licensed electrician.
- 2. Please read the instruction carefully and save it as you may need it at later time.
- 3. Before you start, **NEVER** attempt any work without shutting off the electricity until the work is done. A). Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "OFF" position. B). Place the wall switch in the "OFF" position.
- Mounting surface should be clean, dry, flat, strong enough and 1/4" larger than the canopy on all side. Any gaps between the mounting surface and canopy exceeding 3/16" should be corrected as required.
- Make sure that the ceiling or wall can stand the weight of the lamp before fixture. 5.
- Make sure the voltage you are using is **120V**. The maximum wattage is **60W** per bulb. 6.
- Keep the lamp away from acidic and basic objects in case of damaging the surface of the lamp. 7.
- When replacing bulb, you should turn off or unplug the lamp and you must wait until it is cool as bulbs get hot quickly.
- The safety instructions appearing in this manual are not meant to cover all possible conditions that may occur. It must 9. be understood that common sense, caution and care must be used with any electrical products.

IMAGE FOR FINISHED PRODUCT:



TOOLS REQUIRED (NOT INCLUDED):

Before doing assembly and installation please prepare the needed tools as below picture




Page: -1-/3 www.ihomeangel.com



\boxtimes

PARTS TYPE & QTY INCLUDING:

- (A) Green ground screw (1)
- (B) Mounting plate (1)
- (E) Canopy (1)
- (F) Ball nut (2)
- (G) Loop (2)
- (H) Quick link (2)
- (I) Chain (1)
- (J) Lantern (1)



ACCESSORIES & QTY ENCLOSED:

- (C)Plastic Wire Connectors (3)
- (D) Mounting screw (2)

ASSEMBLY & INSTALLATION INSTRUCTIONS:


1. Carefully remove the fixture from the carton and check that all parts and accessories are included as shown in the above illustration.

2. Turn off power

Before you start to make installation, NEVER attempt any work without shutting off the electricity until the work is done. A). Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "OFF" position.

B). Place the wall switch in the "OFF" position.

3. Make pre-installation



Step A1: By measuring, determine the correct number of links needed for proper hanging height. Using the chain pliers, disconnect and discard the remaining chain.

Step A2: Attach a quick link(H) to loop (G)on the top of fixture and to connect the end of chain(I).Do the same with the

www.ihomeangel.com Page: -2-/3

support@ihomeangel.com




another end .

Step A3: Gently lace wires through chain (I), loop(G) to the top of mounting plate (B)

Step A4: If needed, cut off the wires length of fixture. At this point, need take note of length should be available for the following mounting. the length from the top of nipple are at least 6".

4. Make installation



Step B1:Unscrew the ball nut (F) from canopy (E)then gently remove the moungting plate (B).


Step B2:Attach the mounting plate (B) to outlet box with mounting screws (D).

Step B3: Make wire connections

Connect wires as below wires connecting shown. TAKE NOTE OF YOUR COLOR OF FIXTURE, NEVER CONNECT

WIRES TO GROUND WIRES


Connect ground wire according to below chart



Connect wires according to below chart

Connect Black or Red Supply Wire to:	Connect White Supply Wire to:
Black	White
*Parallel cord (round & smooth)	*Parallel cord (square & ridged)
Clear, Brown, Gold or Black without tracer	Clear, Brown, Gold or Black with tracer
Insulated wire (other than green) with copper conductor	Insulated wire (other than green) with silver conductor

*Note: When parallel wires (SPT I & SPT II) are used. The neutral wire is square shaped or ridged and the other wire will be round in shape or smooth (see illus.)



Twist plastic wire connector until wires are tightly joined together, wrap each connector with approved electrical tape. Be sure that no wire strands are exposed and then carefully tuck all wires into the outlet box .

Step B4: Raise canopy (E) to ceiling and secure canopy (E) in place by tightening ball nuts (F) onto screws

Step B5: Install bulb (Not included. Please do not exceed the maximum capacity recommended on the socket.)

5. Check everything installed properly, then you could turn on the light. Enjoy!

CLEANING

To clean, wipe fixture with a soft cloth. Clean glass with a mild soap. Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.

ORDERING PARTS

Keep this sheet for future reference, and in case you need to order replacement parts. All parts for this fixture can be ordered from place of purchase. Be sure to use exact wording from illustration when ordering parts.

www.ihomeangel.com Page: -3-/3