


+1 850 296 2377 Working hours: Mon - Fri 9:00 a.m. - 16:00 p.m. EST uolfin@newdecorworld.com

# Item Number: A03619\A03620

**WARNING** (To reduce the risk of fire, electric shock, or injury to persons):

- We suggest installation by a licensed electrician.
- 2. Please read the instruction carefully and save it as you may need it at later time.
- Before you start, **NEVER** attempt any work without shutting off the electricity until the work is done. A). Go to the main 3. fuse, or circuit breaker, box in your home. Place the main power switch in the "OFF" position. B). Place the wall switch in the "OFF" position.
- Mounting surface should be clean, dry, flat, strong enough and 1/4" larger than the canopy on all side. Any gaps between the mounting surface and canopy exceeding 3/16" should be corrected as required.
- Make sure that the ceiling or wall can stand the weight of the lamp before fixture. 5.
- Make sure the voltage you are using is 120V. The maximum wattage is 40W per bulb. 6.
- Keep the lamp away from acidic and basic objects in case of damaging the surface of the lamp. 7.
- When replacing bulb, you should turn off or unplug the lamp and you must wait until it is cool as bulbs get hot quickly. 8.
- The safety instructions appearing in this manual are not meant to cover all possible conditions that may occur. It must 9. be understood that common sense, caution and care must be used with any electrical products.


#### **IMAGE FOR FINISHED PRODUCT:**



Page: -1-/4


# TOOLS REQUIRED (NOT INCLUDED):

Before doing assembly and installation please prepare the needed tools as below picture



### PARTS TYPE & QTY INCLUDING:

- (C) Round mounting plate (1)
- (D) Green ground screw (1)
- (E) Canopy (1)
- (F) Knob ball (2)
- (G) loop (4)
- (H) Quick link (4)
- (I) Chain (2)
- (J) Threaded nipple (2)
- (K) Arm (4)
- (L) Socket cup (8)



## **ACCESSORIES & QTY ENCLOSED:**

- (A) Plastic wire connector (3)
- (B) Mounting screw (2)

### **ASSEMBLY & INSTALLATION INSTRUCTIONS:**

- 1. Carefully remove the fixture from the carton and check that all parts and accessories are included as shown in the above illustration.
- 2. Turn off power


Before you start to make installation, NEVER attempt any work without shutting off the electricity until the work is done. A). Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "OFF" position.

B). Place the wall switch in the "OFF" position.




3. 1) Slip loops (G) over the wires and then thread it into the top of threaded nipple (J).

2) Adjust the arms(K) to the right position.




4. 1) Open the quick link (H) of the chain (I), then connect the canopy (E) and the chain (I) together. Close quick link (H).


2) Open the quick link (H) of the chain (I), then connect the chain (I) and the loop (G) together. Close quick link (H).



5. Unscrew the knobs (F) from canomounting plate (C).



6. Attach the mounting plate (C) to outlet box with the mounting screws (B).



Page: -3-/4



# ■ uolfin@newdecorworld.com

#### 7. Make wire connections

A

**GREEN GROUND** 

SCREW

# Connect wires as below wires connecting shown. TAKE NOTE OF YOUR COLOR OF FIXTURE, NEVER CONNECT

#### **WIRES TO GROUND WIRES**

### Connect ground wire according to below chart

# **OUTLET BOX** FIXTURE GROUND GROUND **FIXTURE** GROUND **OUTLET BOX**

GROUND


**GREEN GROUND** 

SCREW

### Connect wires according to below chart

Connect Black or Red Supply Wire to:	Connect White Supply Wire to:
Black	White
*Parallel cord (round & smooth)	*Parallel cord (square & ridged)
Clear, Brown, Gold or Black without tracer	Clear, Brown, Gold or Black with tracer
Insulated wire (other than green) with copper conductor	Insulated wire (other than green) with silver conductor

\*Note: When parallel wires (SPT I & SPT II) are used. The neutral wire is square shaped or ridged and the other wire will be round in shape or smooth (see illus.)




Twist plastic wire connector until wires are tightly joined together, wrap each connector with approved electrical tape. Be sure that no wire strands are exposed and then carefully tuck all wires into the outlet box.

CUPPED


WASHER

8. Raise canopy (E) to ceiling and secure canopy (E) in place by tightening knobs (F) onto the threaded nipple on mounting plate.





9. Install bulb (not included) (Please do not exceed themaximumcapacityrecommendedonthesocket.)



Check everything is already installed properly, then you could turn on the light. Enjoy!

### **CLEANING**

To clean, wipe fixture with a soft cloth. Clean glass with a mild soap. Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.

# **ORDERING PARTS**

Keep this sheet for future reference, and in case you need to order replacement parts. All parts for this fixture can be ordered from place of purchase. Be sure to use exact wording from illustration when ordering parts.