


ASSEMBLY INSTRUCTION

ITEM : N715P180448

DINING TABLE



If you have any questions, please feel free to contact us.
Email: lowes.team@qualfurn.net

ASSEMBLY INSTRUCTION

ITEM : N715P180448

Important Note !

Please read these instructions fully before starting assembly:


1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts
2. Kindly follow the assembly instructions step by step.
3. Do not tighten all screws and bolts until the table is fully assembled.
4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.
5. Parts of the assembly will be easier with 2 people.

Care and maintenance:

Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.









ASSEMBLY INSTRUCTION

ITEM : N715P180448



ASSEMBLY INSTRUCTION


ITEM : N715P180448

| Part List For One | Hardware List For One |
|--|--|
| Ⓐ  | ①  M4*32mm |
| TABLE TOP (1PC) | WOOD SCREW (12PCS) |
| Ⓑ  | ②  M6*60mm |
| LEG (2PCS) | BOLT (8PCS) |
| Ⓒ  | ③  |
| SUPPORT (2PC) | SPRING WASHER (8PCS) |
| | ④  |
| | ALLEN KEY (1PC) |
| | ⑤  |
| | WOOD DOWEL (4PCS) |


ASSEMBLY INSTRUCTION

ITEM : N715P180448





STEP 1



WARNING: Please install the parts with care and on a clean surface.





NOTE : Do not fully tighten the bolt

| BOLT M6*60mm | SPRING WAHER | ALLEN KEY | WOOD DOWEL |
|---|--|---|---|
|  |  |  |  |
| ② x 8 | ③ x 8 | ④ x 1 | ⑤ x 4 |

STEP 2

WARNING: Place the Table Top panel on a clean and smooth surface to avoid scratches!

- * There are no pre-drilled holes on the table , please align the legs with the marking line provided and screw directly with screwdriver or electric drill.



NOTE: Fully tighten all bolts with Allen Key (4) to secure all legs.

| WOOD SCREW M4*32mm |
|---|
|  |
| ① x 12 |

ASSEMBLY INSTRUCTION

ITEM : N715P180448

COMPLETE

