
USE AND CARE MANUAL

TABLE LAMP Model number: 21367



Hardware (Parts are not to scale)

H1	
Socket ring (Pre-assembled on the assembly (B))	socket of the socket
1 pc	

THIS MANUAL CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

IMPORTANT SAFETY INFORMATION

- This lamp is for indoor use only. The lamp should not be used near water. Never immerse the lamp in water
 or other liquids.
- Never cover the lamp with any object including cloth or paper as this is a fire hazard.
- Do not handle the bulb immediately after the light is turned off as it will be hot.
- This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

PREPARATION


Before beginning assembly, installation or operation of product, make sure all parts are present. Compare
parts with package contents list and diagram on the previous page. If any part is missing or damaged, do
not attempt to assemble, install or operate the product. Contact customer service for replacement parts.

ASSEMBLY

SHADE ASSEMBLY

1 Assembling the shade

- Place the shade (A) from the box.
- Gently press the edge of the shade panel with your hand to turn the shade panel over as shown in the diagram.




ASSEMBLY

LAMP ASSEMBLY

1 Assembling the tubes to the base

- Pull the excess power cord through the base (E).
- Tighten the tube (D) onto the base (E).
- Tighten the tube (C) onto the tube (D).
- Tighten the socket assembly (B) onto the tube (C).


NOTE: Do not twist the power cord.



3 Assembling the bulb


- Install the light bulb (H2) into the socket. Use one MAX 60W medium base (E26) type "A" bulb (recommended).
- Plug into the wall outlet, pull the pull chain of the socket assembly (B) and enjoy.

NOTE: You can also use one MAX 16W medium base (E26) self-ballasted LED bulb. Do not exceed the recommended wattage.



2 Assembling the shade

- Unscrew the socket ring (H1) from the socket of the socket assembly (B).
- Place the shade (A) over the socket of the socket assembly (B) and secure with the socket ring (H1).



CLEANING

- Do not use any cleaners with chemicals, solvents, or harsh abrasives. Use only a dry, soft cloth to dust or wipe carefully.
- To clean the fixture, pull the plug from the wall outlet. Use a dry or slightly dampened, clean cloth to wipe the exterior surface of the fixture.

TROUBLESHOOTING

- The light does not come on at all:
 - a) Check whether the bulb was burned out.
 - b) Ensure the power supply is turned on.
 - c) Ensure the cord is plugged into an outlet.
 - d) Ensure the circuit breaker is set in the "ON" position.
- Fuse blows or circuit trips when light is turned on.
 - a) Check for crossed wires, ensure wiring is correct.