


item # CY1904


Assembly Instructions

3 Pieces Outdoor Wicker Sectional Conversation Set




1	Lounge Sofa	3	Coffee Table
2	Loveseat Sofa		


HARDWARE INCLUDED




#1



#2



#3




AA



BB




CC



DD



EE


















FF



GG

Part	Description	Quantity	Part	Description	Quantity
#1	Allen Wrench	2	CC	M6*35 Bolt	24
#2	Ratchet Wrench	1	DD	M6*45 Bolt	18
#3	Hex Wrench	2	EE	Nut	18
AA	Pin	2	FF	Adjustable Feet	13
BB	Washer	60	GG	"V" Clip	2

PACKAGE CONTENTS

Part	Description	Image	Quantity	Part	Description	Image	Quantity
A	Lounge Sofa Right Arm		1	I	Loveseat Sofa Side		1
B	Lounge Sofa Backrest		1	J	Coffee Table Top		1
C	Lounge Sofa Seat		1	K	Coffee Table Side		2
D	Lounge Sofa Side		1	L	Coffee Table Front/Back		2
E	Lounge Sofa Front		1	M	Ottoman Cushion		1
F	Loveseat Sofa Left Arm		1	N	Back Cushion		3
G	Loveseat Chair Backrest		1	O	Armrest Cushion		2
H	Loveseat Sofa Seat		1	P	Seat Cushion		3

