MANTEL

MODEL X6215-1WHT X6215-1SND X6215-1MAH X6215-1SBL



PACKAGE CONTENTS



HARDWARE CONTENTS

вв









CC

DD



GG



X2 00-00 X2 X1 (a) mm> X2 (4*35MM) X2 (4*15MM)

SS

Safety Chain Qty.1

Bolt Qty.33

Metal Connector Qty.33

Cabinet Door Hinge Qty.4

Panel Screw Qty.24

Screw M4*25 Qty.2

Shelf Pin Qty.8

Handle Qty.2

PACKAGE CONTENTS

PART	DESCRIPTION	QTY.	PART NO.
А	Base	1	
В	Left Side Panel	1	
С	Right Side Panel	1	
D	Left Inner Panel	1	
E	Right Inner Panel	1	
F	Top Shelf	1	
G	Lower Back Panel	2	
Н	Top Shelf Divder	1	
I	Upper Back Panel	1	
J	Тор	1	
К	Left Trim Panel	1	
L	Right Trim Panel	1	
М	Shelf Rail	1	
N	Adjustable Shelf	2	
0	Left Door	1	
Р	Right Door	1	
AA	Bolt	33	
BB	Metal Connector	33	
СС	Cabinet Door Hinge	4	
DD	Panel Screw	24	
EE	Screw M4*25	2	
FF	Shelf Pin	8	
GG	Handle	2	
SS	Safety Chain	1	

Some parts and specifications may change without notice.

Carefully remove all pieces from the carton and make sure that you have all parts listed (refer to parts list on page 2-3).



















































IMPORTANT-Safety Chain Installation

WARNING:

This mantel is heavy furniture. Please be sure to correctly attach the safety chain to both the mantel and an adjacent wall. Failure to do so can cause serious injury or death.



INSTALLATION:

- Assemble the mantel and place it in position
- Attach one end of the chain to a wall stud using the screw included
- Attach the other screw through a link in the chain to the center of the mantel's top board(you may need to drill a small starter hole).Put the screw through the chain link that allows the least amount of slack in the chain.
- Carefully test that the installed chain adequately prevents tipping or tilting of the mantel.

NOTE: The chain must be as short as possible to prevent the mantel tippping forward. Do not allow slack in the chain.