


Item Number: A05015

WARNING (To reduce the risk of fire, electric shock, or personal injury):


1. Please read the instruction carefully and save it as you may need it at a later time.
2. Before you start, **NEVER** attempt any work without shutting off the electricity until the work is done.
 - » Do not turn on the power supply until the installation is finished.
3. Installation place should be clean and dry.
4. Make sure that the installation place can stand the weight of the lamp before installation.
5. Make sure the voltage you are using is **120V**. The maximum wattage is **Type A, Max 100W** per bulb.
6. Keep the lamp away from acidic and alkaline substances in case of damaging the surface of the lamp.
7. When replacing bulbs, you should turn off or unplug the lamp and you must wait until it is cool as bulbs get hot quickly.
8. The safety instructions appearing in this manual are not meant to cover all possible conditions that may occur. It must be understood that common sense, caution and care must be used with any electrical products.

IMAGE FOR FINISHED PRODUCT:



PARTS TYPE & QTY INCLUDING:

- (A) Lock (1)
- (B) Lampshade (1)
- (C) Harp (1)
- (D) Socket assembly(1)
- (E) Body (1)
- (F) Wire (1)




ASSEMBLY & INSTALLATION INSTRUCTIONS:

1. Carefully remove the fixture from the carton and check that all parts and accessories are included as shown in the above illustration.


2. Turn off power

Do not turn on the power supply until the installation is finished.


3 » Screw socket assembly (D) into the top of body (E).




- 4 » 1) Push the two caps of harp (C) upwards.
 2) Press harp (C) inward with your hand, taking care not to put your hand on the flat plate.
 3) Keep the pressed shape, and then put it in the proper position of socket assembly (D).
 4) Return the two caps to them original place.
 • **Please refer to the illustration for above steps.**



- 5 » 1) Remove lock (A) from harp (C).
 2) Place lampshade (B) on harp (C), and then fix them with lock (A) as shown in the illustration.



- 6 » Install the bulb (not included) (Please do not exceed the maximum wattage recommended on the socket.)
 • **The red circle on the right figure is the switch of the light. When you want to turn on the light, please turn it as shown in the figure.**



7. Check everything is already installed properly, then you could turn on the light. Enjoy!

ORDERING PARTS

Keep this sheet for future reference in case you need to order replacement parts. All parts for this fixture can be ordered from the place of purchase. Be sure to use exact wording from illustration when ordering parts.

CLEANING

To clean, wipe the lampshade with a soft cloth. Clean glass body with a mild cleaner (such as mild and non-abrasive soap). Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.