


# ASSEMBLY INSTRUCTIONS

## DINING TABLE




**N717P182236**

### **IMPORTANT NOTE:**

- PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE TABLE IS FULLY SET-UP.

## CARTON CONTENT:

N717P182236 :



1 x 1



2 x 4


### TABLE PART LISTS

NO.	DESCRIPTION	SKETCH	QTY
1	TABLE TOP		1 PC
2	TABLE LEG		4 PCS




### TABLE HARDWARE LISTS

NO.	DESCRIPTION	SKETCH	QTY
A	JCBC BOLT M8 X 60 mm		8 PCS
B	SPRING WASHER M8		8 PCS
C	FLAT WASHER M8		8 PCS
D	ALLEN KEY M5		1 PC
SCREW DRIVER			NOT INCLUDED


### STEP 1




REMOVE BLOCK  
PROTECTION



STEP 2




ASSEMBLY  
COMPLETE !



# ASSEMBLY INSTRUCTIONS

## DINING CHAIR




**N717P182237**

### **IMPORTANT NOTE:**


- PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE CHAIR IS FULLY SET-UP.

## CARTON CONTENT:


N717P182237 :



1 x 4



2 x 4



3 x 4



4 x 4



5 x 4



### CHAIR PART LISTS

NO.	DESCRIPTION	SKETCH	QTY
1	CHAIR BACK		4 PCS
2	SIDE RAIL - R		4 PCS
3	SIDE RAIL - L		4 PCS
4	LEG FRAME		4 PCS
5	WOODEN SEAT		4 PCS



### CHAIR HARDWARE LISTS

NO.	DESCRIPTION	SKETCH	QTY
A	JCBC BOLT M6 X 50 mm		32 PCS
B	CSK SCREW M4 X 32 mm		20 PCS
C	CSK SCREW M3.5 x 12 mm		24 PCS
D	NYLON WASHER M6		32 PCS
E	L - BRACKET 2 HOLES		12 PCS
F	ALLEN KEY M4		1 PC
SCREW DRIVER			NOT INCLUDED

### STEP 1



STEP 2



STEP 3

