



ASSEMBLY INSTRUCTION
















ITEM NO. ARMCHAIR WF301654




IMPORTANT NOTE:

- ① PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR A CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- ② BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY.
- ③ DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE CHAIR IS FULLY SET-UP.




Part List		Hardware List	
Ⓐ		①	 Ø 5/16" x 60mm
	BACK CUSHION (1PC)		BOLT (3PCS)
Ⓑ		②	 Ø 1/4" x 50mm
	SEAT CUSHION (1PC)		BOLT (10PCS)
Ⓒ		③	 Ø 5/16" x 13mm
	BACK FRAME (1PC)		LOCK WASHER (3PCS)
Ⓓ		④	 Ø 5/16" x 19mm
	SEAT FRAME (1PC)		FLAT WASHER (3PCS)
Ⓔ		⑤	 Ø 10 x 30mm
	ARMREST – LEFT (1PC)		DOWEL (6PCS)
Ⓕ		⑥	 M4 x 45mm
	ARMREST – RIGHT (1PC)		SCREW (4PCS)
Ⓖ		⑦	 4mm
	FRONT STRETCHER (1PC)		ALLEN KEY (1PC)
Ⓖ			
	BACK STRETCHER (1PC)		


STEP 1:




STEP 2:




STEP 3:



STEP 4:



STEP 5:



COMPLETED

