




## Assembly Instructions



# TXRT248

## Monterey Bay Round 48\" Dining Table

### 20-Year Warranty

To view our full warranty, please visit  
[trexfurniture.com/warranty](http://trexfurniture.com/warranty)

### Share your space

We love to see where our furniture  
ends up — snap a pic and share  
it with us on Facebook!  
[facebook.com/trexfurniture](https://facebook.com/trexfurniture)

### Having Trouble?

If you have questions or concerns regarding  
assembly instructions or missing parts,  
please contact us at (877) 907-TREX (8739)  
or email [support@trexfurniture.com](mailto:support@trexfurniture.com)

### Cleaning Tips

Keep your Trex Outdoor Furniture™  
looking brand new:

#### For a quick clean:

Simply wipe down with soap and water.


#### For a deeper clean:

You'll need:




- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth  
and let it sit on the lumber for a few  
minutes (this will not affect the color).  
Then, loosen any dirt and debris that  
may catch in surface grooves with a  
soft bristle brush; hose down to rinse.


TOOLS




PARTS




1





2



3




4





## Assembly Instructions



**NO ASSEMBLY REQUIRED**

# TXD200

## Monterey Bay Dining Arm Chair

[trexfurniture.com](http://trexfurniture.com)

06/09/2017

## ..... 20-Year Warranty .....

To view our full warranty, please visit  
**[trexfurniture.com/warranty](http://trexfurniture.com/warranty)**

## ..... Having Trouble? .....

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at **(877) 907-TREX (8739)** or email **[support@trexfurniture.com](mailto:support@trexfurniture.com)**

## ..... Share your space .....

We love to see where our furniture ends up — snap a pic and share it with us on Facebook!  
**[facebook.com/trexfurniture](https://facebook.com/trexfurniture)**

## ..... Cleaning Tips .....

Keep your Trex Outdoor Furniture looking brand new:

### For a quick clean:

Simply wipe down with soap and water.

### For a deeper clean:

You'll need:

- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.