
### +1 850 296 2377 Working hours : Mon - Fri 9:00 a.m. - 16:00 p.m. EST

#### Item Number: A03527

WARNING (To reduce the risk of fire, electric shock, or injury to persons):

- 1. We suggest installation by a **licensed electrician**.
- 2. Please read the instruction carefully and save it as you may need it at later time.
- 3. Before you start, **NEVER** attempt any work without shutting off the electricity until the work is done. A). Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "**OFF**" position. B). Place the wall switch in the "**OFF**" position.
- 4. Mounting surface should be clean, dry, flat, strong enough and 1/4" larger than the canopy on all side. Any gaps between the mounting surface and canopy exceeding 3/16" should be corrected as required.
- 5. Make sure that the ceiling or wall can stand the weight of the lamp before fixture.
- 6. Make sure the voltage you are using is **120V**. The maximum wattage is **60W** per bulb.
- 7. Keep the lamp away from acidic and basic objects in case of damaging the surface of the lamp.
- 8. When replacing bulb, you should turn off or unplug the lamp and you must wait until it is cool as bulbs get hot quickly.
- 9. The safety instructions appearing in this manual are not meant to cover all possible conditions that may occur. It must be understood that common sense, caution and care must be used with any electrical products.

#### **IMAGE FOR FINISHED PRODUCT:**




www.ihomeangel.com

support@ihomeangel.com

### TOOLS REQUIRED (NOT INCLUDED):

Before doing assembly and installation please prepare the needed tools as below picture



- 1. Carefully remove the fixture from the carton and check that all parts and accessories are included as shown in the above illustration
- 2. Turn off power

Before you start to make installation, NEVER attempt any work without shutting off the electricity until the work is done. A). Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "OFF" position. B). Place the wall switch in the "OFF" position.


www.ihomeangel.com

# +1 850 296 2377 Working hours : Mon - Fri 9:00 a.m. - 16:00 p.m. EST Support@ihomeangel.com

 According your desired hanging length to select and use the tubes (I) then pass the wires through the tubes(I) to the top of loop .Gently pull wires and thread the tubes (I)onto the fixture (0) till tight

Unscrew the ball knobs (H)from the canopy (E) then remove the mounting plate (B)
Attach a quick link (G)to loops(F) to connect the cannopy (E) and tube(I) Gently and carefully pass the wires through the loop(F) to the top of


5. Attach the mounting plate(B) to outlet box with the mounting screws(D)



cannopy (E)

Connect wires as below wires connecting shown. TAKE NOTE OF YOUR COLOR OF FIXTURE ,NEVER CONNECT WIRES TO GROUND WIRES


### Connect ground wire according to below chart





## Connect wires according to below chart

Connect Black or	Connect
Red Supply Wire to:	White Supply Wire to:
Black	White
*Parallel cord (round & smooth)	*Parallel cord (square & ridged)
Clear, Brown, Gold or Black	Clear, Brown, Gold or Black
without tracer	with tracer
Insulated wire (other than green)	Insulated wire (other than green)
with copper conductor	with silver conductor
*Note: When parallel wires (SPT I & a are used. The neutral wire is square s or ridged and the other wire will be re shape or smooth (see illus.)	shaped

www.ihomeangel.com









### +1 850 296 2377 Working hours : Mon - Fri 9:00 a.m. - 16:00 p.m. EST

### support@ihomeangel.com

Twist plastic wire connector(A) until wires are tightly joined together, then carefully stuff all wires into the outlet box

 Raise canopy (E) to ceiling and secure canopy (E) in place by tightening knobs (H) onto the threaded nipple on mounting plate





 Unscrew the socket ring (K) and sleeve (L) from the socket(N). Gently and carefully position glass (M) and sleeve (L) onto the socket (N), then use the spacer (J) to thread the socket ring (K)till snug for securing the glass shade in place . Install the bulb (not included) (Please do not exceed the maximum

capacity recommended on the socket.)

9. Check everything are already installed properly, then you could turn on the light. Enjoy!

### CLEANING

To clean, wipe fixture with a soft cloth. Clean glass with a mild soap. Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.

### ORDERING PARTS

Keep this sheet for future reference, and in case you need to order replacement parts. All parts for this fixture can be ordered from place of purchase. Be sure to use exact wording from illustration when ordering parts.