INSTALLATION GUIDE FOR ASH28858D0, ASH28858D1, ASH28858D2 and ASH28858D3



SAFETY INFORMATION

Released Date: 2021-10-15

Please read and understand this entire manual before attempting to assemble, install or operate the product.


WARNING

 RISK OF ELECTRIC SHOCK - Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.

CAUTION

- For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.

TOOLS REQUIRED




Ratings	120Vac, 60Hz	
	Model No.	Wattage
	ASH28858D0	30W
	ASH28858D1	30W
	ASH28858D2	30W
	ASH28858D3	30W

CARE AND MAINTENANCE

 Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage the finish.


If you need further assistance email customercare@ashleyharbour.com.

PACKAGE CONTENTS



MOUNTING HARDWARE










BB Wire Connector




CC Outlet Box Screw









Your installation is now complete! Restore electricity and save this sheet for future reference.