MAGNETIC DRILL

OPERATION INSTRUCTIONS





Read through carefully and understand these instructions before use.

FEATURES AND USES

Magnetic seat drill is a can be adsorbed on iron and steel workpiece surfaces, side, top surface, surface shall be according to the surface making special magnetic seat, production cycle day 18) for drilling electric tools, is extensively used in the construction, bridge, boiler, shipbuilding and other industries, for large iron and steel workpiece and some field work with drilling and flashlight ring or inconvenience processing can use magnetic base drill, it is convenient to use, flexible, can reduce the labor intensity, improve machining precision and work efficiency.

Because it has a unique role in the drilling of large holes(in the 450 largest steel can be drilled 180mm) has a unique role, so it can be used to replace the radial drilling machine.

MATTERS NEEDING ATTENTION

- 1. The magnetic seat drill is provided with a safety protection belt,and the magnetic seat drill is necessary to fix the magnetic seat in thehanging operation, so as to prevent the occurrence of the accident caused by the sudden power failure or the power failure.
- 2. when cooling the drill bit, the coolant should be as far as possible to the drill bit, do not make the coolant splash, especially, not the residual liquid in the magnet and the adsorption surface
- 3. in check, maintenance before, be sure to turn off the switch and unplug the power plug
- 4. the magnetic seat drill shall be deposited in a dry, clean and non orrosive environment in which the child is not to be taken
 - 5. maintain a bit sharp, wrench keys should be from the chuck.

SAFETY INSTRUCTIONS

Warning: when using power tools, in order to reduce the fire electric shock and personal injury and other accidents, shall comply with the following basic safety issues

- 1.keep the workplace clean. A messy workplace and work station will lead to an accident.
- To ensure that the working environment of Botox. Electric tools do not get wet in the rain In wet places and flammable and explosive places. Workplace need to maintain sufficient brightness.
- 3. beware of electric shock accident. Avoid body contact with objects on the ground.
- 4.do not let children close. No idlers in the workplace, but can not let people touch the tool or the power supply connecting wires.
- 5. The dress to the right. Do not wear loose fitting clothing or jewelry, so as not to get involved in rotating parts. Outdoor work, wear non slip shoes Wear long hair should work wear hats.

- 6. the use of protective equipment. During the operation, wearing goggles and wearing a dust mask.
- 7. Do not damage the wire. Yank the wire plug is strictly prohibited Must avoid wire touch hot, grease and sharp metal edges, with the handle to keep clean and dry, stained with grease.
- Use fixed workpiece clamp or vise clamping workpiece than by hand fixed work safety.
- 9. not to stretch out the more work. To maintain stability and balance of the body when the job.
- 10. maintenance tools. Keep the knife sharp, cleaning should be conducive to the safe operation.

Specification for lubrication and replacement of spare parts Regular inspection of the wire, such as damage should be commissioned by the professional sector Fix.

- extension cables for outdoor use. Special extension cable must be used for outdoor work.
- work should be cautious when working, Should concentrate on the same time.
- 13. note: you must use the instructions provided in the spare parts to avoid personnel injury and electric shock.
- 14. tools are to be repaired and maintained by a full time personnel. Electric tools are designed and manufactured in accordance. with the relevant safety standards. Full time personnel should use the spare parts which are used in the original production. Otherwise, it wil cause harm to the users.
- 15. Do not push hard piezoelectric drill. When the operation is blocked, will drill return to prevent overload of electric drill. All abnormal decrease in case of speed should be immediately relax feed. Drill for some reason the sudden braking when must immediately cut off the power supply.
 - 16. work must be put on the cable body back, away from the drill bit.
- 17. plug, the switch should be in the open position, any extension or cable shall not be removed.
- 18. excessive roughness of the adsorptio ion surface has a certain effect on the suction force of the magnetic seat drill, so we should first test to prevent the occurrence of the accident.
- 19. In the general field using magnetic base drill should take safety protection measures, such as assembly of leakage protector(including leakage protection plug, socket etc.) Otherwise, the user must wear insulated gloves, wear insulated shoes or stand on the insulating mat In wet places or metal frame upper conductive good workplace, assembly nominal leakage action current is not greater than 30mA, action time is less than 0.1s leakage protector.

Grounding device

This tool should be properly grounded, in order to avoid the operator by an electric shock. Grounding device should be in accordance with the standard wire and is accompanied by a grounding plug connected with special line. Never will be on the ground wrong connection on the FireWire or phase joint.

While connecting the power supply socket should be and is connected to the ground eternal grounding device is connected, so that it can be fixedly connected with the yellow green wire plug hole and a lug is communicated with the earth.

Extension cable

Only allow the use of standard of extending cable, with grounding type plug and socket to supply power to the tools, such as cable damage should be repaired or replaced.

Electrical safety

Tool in front of the power supply connection, be sure to note whether the power supply voltage and marked on the nameplate voltage the same Power supply voltage is higher than the tools applied voltage, will give the user the accident. Also damaged tools. Power supply voltage is too lower than the tools required voltage, there will be loss in motor. Therefore, such as to determine the power voltage, must not be casually plug.


Features and uses

Magnetic seat drill is by a DC electromagnetic sucker adsorption in the steel surface with the drill for rotary cutting processing of portable power tools. It and the ordinary drill difference is at the level of the iron and steel, top surface and on-site engineering operations: can also solve the hand-held electric drill high labor intensity and low accuracy The product conforms to the standard of the safety of the CB38836< hand-held motor and the JB/T9609< magnetic seat drill.

The product can twist drill dilling, and drilling holes with hollow drill tool.

TECHNICAL DATA

Specifications	Cord drilling 40H	Cord drilling 50H	Cord drilling 65H	Cord drilling 80H	13	16	23	28	32
Rated Input Power(W)	1100	1550	1700	1800	1060	1100	1200	1550	1800
No-load Speed(RPM)	550	500	480	450	600	550	500	480	450
Max. Ttraction(N)	12000	15500	16000	18000	12000	12000	13000	16000	18000
Twist Drill(mm)	Ø1.5-13	Ø1-23	Ø1-23	Ø1-23	Ø1-13	Ø1-16	Ø1-23	Ø1-23	Ø1-23
Drilling Depth(mm)	50	180	180	180	160	160	180	180	180
Spindle Diameter(mm)	19	19	19	19			19	19	19
Core Drill(mm)	Ø12-40	Ø12-50	Ø12-65	Ø12-80			Ø12-45	Ø12-65	Ø12-80
Drilling Depth(mm)	50	50	50	50			50	50	50
Gross Weight(kg)	14	19.5	22	24	12	13	19.5	22	24
Max. Travel(mm)	180	210	210	220			210	210	220
Size(cm)	26x22x35	30x24x41	30x24x41	30x24x45	24x20x32	24x20x32	30x24x41	30x24x41	24x20x32



INSTRUCTIONS

The use of prior understanding magnet drill structrue, electromagnetic sucker, electric drill and the operation of generation transmission.

- 1 electric drill
- 2 feed handle
- 3 rack
- 4 electromagnet switch
- 5 electric switch
- 6 electromagnet

INSTALL DRILL

Note: be sure to close the switch and pull the plug off before you install or remove the drill bit.

Turn the feed handle, the electric drill rose to the highest position (when necessary lateral magnetic drill), mounted on the drill, Remove the same.

For Morse taper shank drill note flat tin tall alignment sleeve on a waist slot in silver sleeve. Demolition bits will be inclined iron insert sleeve waist groove by hannering wedge resulting bit off. For the drill chuck clamping bit must be key wrench.

JOB FREPARATION

Buckle the safety belt.

The magnetic seat drill placed at the desired drilling near the site of, and choose the suitable adsorption material and will handle hole of the security door with a head wear machine frame, on the other end of the fetter on sturdy frame wear closely in and leave about 100mm length head and tighten the buckle bolt. Hand pulled off without loosening and displacement.

The operation steps

- 1. Insert the power plug, the drill is roughly aligned to the processing position, and then the electromagnet switch is turned on, so that the electromagnet adsorption on the surface of the iron and steel and other magnetic materials (generally plate thickness should be greater than 20mm).
- For a magnetic seat equipped with a rotary table, loosen the handle of the turntable, move the machine frame to drive the machine frame to make the bit towel center aligned to the working position, and then screw down the handle.
- The support screw should be adjusted to make it light to the surface of adsorption.
 - 4. The open electric switch.
 - The grip feed handle slowly drilling operations.

Special note: for three-phase magnetic base drill should pay attention to rotation of the electric drill, when does not meet the requirements will wire the two wires (phase)swap, confirming the direction of rotation of the drill right. Never a wrong connection of grounding wire.

check

Magnetic base drill should be regular inspection and maintenanice you must check the power cord, inner connection, plug, switch is in a good condition, insulation resistance is normal, transmission parts if there is any damage.

Lubrication

Magnet drill in the transmission parts(such as: gear, rack) often iub icaied and clean.

keep each parts and replace the same parts.

When dismantling the magnetic base drill should keep each parts, consists of an insulating liner and casing. If there is any damage must change with the same components, assembly should will all parts according to its original position installed, you can not miss.

Quality guarantee period

The company dedicated to customer service, Internal customer service department.

Possible failures and troubleshooting methods

MALFUNCTION	CAUSE	METHOD OF EXCLUSI		
Magnetic Base Wthout Suction	Switch Is Defective Power Off Blown Fuse Solenoid Short Circut Or Burn Teel Parts Circuit Board Burned	1. Repair Switch 2. Fix The Power 3. Replace The Fuse 4. Repair Or Replace Magnetic 2. Change Suction Surfa 6. Replace The Board		
Drill Does Not Runafter The Electrical Connection	Switch Is Defective Joint Loosening The Brush Is Not In Conntact With The Commutator Drill Armature Or Stator Coil Burned	Repair Replacement Switch Check The Drill Portio Off The Tab Repair Or Replace Brushes Exchange Armature Of Stator		
3. Turn The Handle Rails Do Not Exercise	Shaft Key Cut With The Rack Gear Disl Ocation	Replace The Shaft Key Loosen The Screws Underne Ath The Rack, Replace The Armature Or Stator		
4. Magnetic Attraction Small	Adsorption Workbook Small Surface Adsorption Top Strut Not To Suction Surface Diode May Weld	1. Change Suction Surfat Adsorption Surface Or Thick (Thickness ≥15mm) 2. Will Change Adsorptio Or Temporary Welding Thick Suction Surface 3. Strut Top Tight 4. Re-welding		
5. Oval Hole Drilled	Due To The Vibration Drill Leaving Loose Firmware Small Surface Adsorption Surface Debris	Degrees Vertical Correction Torque Fasteners Re-grinding Clear Debris		

AFTER SALES SERVICE CARD

Warranty statement

- 1. The company produces all the tools products from the date of purchase, guarantee of three months.
- 2.due to normal wear and tear, of man-made damage and incorrect operation, in particular the use of the product without instruction, and disassemble or repair are not included in this warranty, overload use tool damage caused by the user themselves
- normal use, the quality of non-human damage occurred their invoices and present the card to the nearest service center for warranty and repair center region is not provided directly contact the dealer or our service center.

Please note shoppers!