









ASSEMBLY INSTRUCTIONS

ITEM NO: 1525

<p>A*1 BODY</p> 	<p>B*1</p>  <p>Insert chair back to the chair base, make sure the slots on the back fully assembled to the bottom part.</p> <p>A*1</p> <p>1</p>	 <p>3</p>	
<p>B*1 BACK</p> 	<p>No.1 and No.2 wire connect with the backrest and chair base. No.3 wire connects with backrest and power cord(D). No.4 wire connects with backrest and remote control(E). No.5 wire connect the motor and the wire from motor remote(C), which use to control the lift / recline function. No.6 wire connect the motor and power source (F).</p>  <p>NOTE</p> <p>1: Two same color wires connect.</p> <p>2: Plug power cord and power source into outlet, then you can use all function.</p> <p>2</p>		
<p>C*1 MOTOR REMOTE</p> 	<p>D*1 MESSAGE POWER CORD</p> 	<p>E*1 MESSAGE REMOTE</p> 	<p>F*1 POWER SOURCE</p> 