



Lighted TV Stand w/Fireplace










ITEM#JX-011 Assembly Instructions












PACKAGE INCLUDE













PART IDENTIFICATION

 1 1x	 2 1x	 3 1x	 4 1x
 5 2x	 6 1x	 7 1x	 8 1x
 9 1x	 10 1x	 11 1x	 12 1x
 13 4x	 14 1x		


PART IDENTIFICATION


 1 1x	 2 1x	 3 1x	 4 1x
 5 2x	 6 1x	 7 1x	 8 1x
 9 1x	 10 1x	 11 1x	 12 1x
 13 4x	 14 1x		

PACKAGE CONTENT

 A 46x+1	Ø15x11MM  B 46x+1	Ø8x30MM  C 23x+1	Ø8x40MM  D 4x+1	
 E 16x	Ø3x14MM  F 24x+1	 G 1x	Ø3.5X12MM  K	
 Fireplace Unit W 1x	 Top Trim X 1x	 Side Trim Y 2x	 Screw Z 12x	 Remote Control H 1x

STEP 2

	
A 10X	C 4X




STEP 3




B

10X






STEP 4




A

16X









STEP 5

	
B 12X	C 4X




STEP 6

		
A 4X	B 4X	C 2X




STEP 7




D

4X






STEP 8


	
B 4X	C 4X




STEP 9




STEP 10



STEP 11


				
W 1X	X 1X	Y 2X	Z 12X	H 1X


NOTE: Make sure two side trims are installed correctly.




NOTE: Do not attempt to install the unit from the front of the mantel. It will not fit.


STEP 12


	
F 24X	G 1X





E 16X





Congratulations on doing it.