

INSTALLATION AND SAFETY INSTRUCTIONS

FOR YOUR SAFETY

WARNING: BE SURE THE ELECTRICITY TO THE WIRES YOU ARE WORKING ON IS SHUT OFF; EITHER THE FUSE IS REMOVED OR THE CIRCUIT BREAKER IS SHUT OFF.

GENERAL

You don't need special tools to install this fixture. Be sure to follow the steps in the order given. Under no circumstances should a fixture be hung on house electrical wires, nor should a swag type fixture be installed on a ceiling, which contains a radiant type heating system. Read instructions carefully. If you are unclear as to how to proceed, consult a qualified electrician.

NOTE: Proper wiring is essential for the safe operation of this fixture.

FIXTURE ASSEMBLY

Carefully removed the fixture from the carton and check that all parts are included as shown in figure. Be careful not to misplace any of the screws or parts, which are needed to install this fixture.

INSTALLATION

Step 1: Attach the nipple(G) to the mounting bracket(A), then secure it with a washer(E) and hex nut(F).

Step 2: Attach the mounting bracket(A) to the outlet box(not included) by using two outlet box screws(B).

Step 3: Secure the top loop(H) to the nipple(G).

Step 4: Install the bulb(not included. Don't exceed the maximum capacity recommended on the Sockets).

Step 5: Place fixture(L) onto the iron rack(M) and secure with screws(N).

Step 6: Choose the length of the chain(K) you need and use a soft cloth and pliers (none included) to avoid damaging the finish of the Chain (K) if any links are being removed. then weave the fixture wire and the fixture ground wire through the chain(K), collar(J) and ceiling plate(I).

NOTE: The top and bottom section of Chain (K) are required.

Step 7: Open the top and bottom section of the chain(K) and attach to the loops then close them.

Step 8: Thread the fixture wire and fixture ground WIRE through the top loop(H), nipple(G) and mounting bracket(A).

Step 9: Pull out the source wires from the outlet box(not included).

Make wire connections with wire connectors(C) as follows:

--Use the wire connector(C) to connect the ridged wire to the white (neutral) supply wire from the outlet box(not included).

--Use the wire connector(C) to connect the smooth wire to the black (live) supply wire from the outlet box(not included).

--Connect the ground wire from the fixture(L) and the ground wire from the outlet box(not included) to the mounting bracket(A) with the ground screw(D).

Step 10: Attach the ceiling plate(I) to the mounting bracket(A) by inserting the top loop(H), then secure it with the collar(J).

CLEANING

To clean, wipe fixture with a soft and dry cloth. Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.

Line art shown may not exactly match the fixture enclosed. However, the installations do apply to this fixture.

ITEM NO:2973

