




05:00

estimated assembly time



1 or more

people required



- Put on mood music!
- To prevent damage to product, use the clean side of package carton or rug as working surface.
- In the event of missing or damaged parts, delivery problems etc., please reach out to our team.
 We will be happy to fix the problem!

care guide

- Clean regularly with a soft and dry cloth.
- To protect finish, avoid use of abrasive cleaners.
- Wipe up spills immediately. Please!


! While assembling the product, tighten the bolts up to 50%. Once all parts are in place, only then fully tighten the bolts.



product parts



A Wooden Top




what's included



(C) - Bolt





(D)- Allen Key x1

OS Orange Sticker

GS Green Sticker

assembly instructions

Friendly Tip: Take a deep breath going in. This may be a tricky part, but nothing too overwhelming. Just follow these steps to the T and the outcome will be worth it!



(!) While assembling the product, tighten the bolts up to 50%. Once all parts are in place, only then fully tighten the bolts.

step 1:

Turn the wooden top of the stool upside down. Unscrew the bolts before starting assembly.




step 2:

Align the metal legs on the wooden top in such a way that the orange (OS) and green stickers (GS) align with their respective others.




step 3:


See the highlighted circles to know where to tighten bolts (C).



step 4:

Place the bolts (C) on the highlighted parts as shown in step 2 and using allen-key (D), tighten them.





you've got a home with us