


















# BT-70621 PARTS

# ASSEMBLY INSTRUCTION

(1)X1 	(10)X4 
(2)X1 	(11)X2 
(3)X1(L)X1(R) 	(12)X2 
(4)X1 	(13)X4 
(5)X1 	(14)X1 
(6)X1 	(15)X1 
(7)X1 	(16)X1 
(8)X1 	(17)X1 
(9)X4 	(18)X1 