



1. Turn off the electrical power to the garbage disposal and disconnect all drain connections. Then remove the garbage disposal. Loosen the three mounting screws on the garbage disposal mounting hardware. Remove the retaining snap ring and hardware from the old disposal rim.
2. Remove the old disposal rim and clean off the old putty from the sink.
3. Apply a generous amount of putty under the flange on the new disposal rim. Position the disposal rim in the sink and press down to compress the putty.
4. Position the garbage disposal mounting hardware onto the disposal rim and re-install the retaining snap ring.
5. Gradually tighten the three mounting screws, alternating the tightening of each screw a few turns at a time until the mounting hardware is securely tightened. Attach the garbage disposal and turn on the water to check for leaks.