


Notice:


- 1. Follow the installation instructions. Please confirm all accessories are preset before installation.
- 2. Do not fully tighten the screws during initial assembly. Fully tighten screws only once all pieces which are correctly assembled.
- 3. If you encounter any problems during installation, please contact our customer service.
- 4. Please unbox the item from the side with an open-label and put a carpet on the floor to avoid scratching it.



Recommended installers:2



Put a carpet on the floor before unpacking




Estimate installation time: 30minutes


PART LIST


Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
A		X1	G		X2
B		X1	H		X2
C		X1			X1
D		X1	J	69	X4
E		X1	K	0	X1
F		X2			


HARDWARE LIST


Item no.	Reference Image	Qty	Item no.	Reference Image	Qty
1	Ø8*30mm	X12+1	9	Ø3*15mm	X8
2		X12+1	10	@MMMMM Ø1/4"*2"	X8
3		X12+1	•	@MM Ø1/4"*1"	X1
4		X8	12		X9
5	Ø3*14mm	X48+4	13		X9
6		X8	14	Ø3*15mm	X24+2
7		X4	15		X1
8		X4	16		X2



















































10







Front-to-Back Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved front-back.

Adjustment range: 4mm

Left-Right Direction Adjustment:

Rotate the screws on the door hinges shown in the image. The door panel can be moved left-right.

Adjustment range: 3mm


Up-Down Direction Adjustment:


Rotate the screws on the door hinges shown in the image. The door panel can be moved up-down.


Adjustment range: 4mm




Common Door Panel Issues:








panels is too large





The two door panels are not at the same height



