


ASSEMBLY INSTRUCTION



NOTES:










- The item is only intended to be used indoors. The product must be assembled and used in accordance with the provisions of the manual.
- It is recommended that assembly is undertaken by about 2 adults. Please read assembly instructions before assembly and strictly adhere to each step outlined. Estimated assembly time is 30 minutes.

WARNING:

- **WARNING FOR YOUNG CHILDREN** - This product contains small components, please ensure that they are kept away from small children while assembling.

1


PARTS LIST

A	B	C	D	E		F		G		H		O	P
													
1PC	1PC	1PC	1PC	1PC		1PC		1PC		1PC		2PCS	2PCS
Q		R		S		T		U		V		W	
													
2PCS		1PC		2PCS		20PCS		1PC		4PCS		2PCS	
a	b	c	e	f	g	i	p	q	r	t	w	x	y
													
1/4*60 2PCS	1/4*45 16PCS	1/4*40 4PCS	1/4*30 8PCS	1/4*16 4PCS	M6*28 1PC	1/4*55 1PC	20PCS	20PCS	10PCS	8PCS	12PCS	2PCS	1PC


2

NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED

①



②




80%


4

NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED

5




6



5


NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED

7



Press down hard

8




80%


6

NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED

9



10




80%


7

NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED

11



12



IMPORTANT: Please completely tighten all the bolts and nuts.