### Item Number: 5069595

**WARNING** (To reduce the risk of fire, electric shock, or injury to persons):

- 1. We suggest installation by a **licensed electrician**.
- 2. Please read the instruction carefully and save it as you may need it at later time.
- 3. Before you start, **NEVER** attempt any work without shutting off the electricity until the work is done. A). Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "**OFF**" position. B). Place the wall switch in the "**OFF**" position.
- 4. Mounting surface should be clean, dry, flat, strong enough and 1/4" larger than the canopy on all side. Any gaps between the mounting surface and canopy exceeding 3/16" should be corrected as required.
- 5. Make sure that the ceiling or wall can stand the weight of the lamp before fixture.
- 6. Make sure the voltage you are using is **120V**. The maximum wattage is **40W** per bulb.
- 7. Keep the lamp away from acidic and basic objects in case of damaging the surface of the lamp.
- 8. When replacing bulb, you should turn off or unplug the lamp and you must wait until it is cool as bulbs get hot quickly.
- 9. The safety instructions appearing in this manual are not meant to cover all possible conditions that may occur. It must be understood that common sense, caution and care must be used with any electrical products.

### **IMAGE FOR FINISHED PRODUCT:**



# TOOLS REQUIRED (NOT INCLUDED):

Before doing assembly and installation please prepare the needed tools as below picture

				Constant of Constant
Ladder	Phillips head.flat blade screwdriver	Electrical tape	Pliers	Wire cutter/Stripper
PARTS TYPE & C (C) Mounting plate ( (D) Green ground sc (E) Canopy (1) (F) Swivel joint (1) (G) Knob ball (2) (H) Tube (I) Screw (6) (J) Arm (3) (K) Glass (6) (L) Nut (12)				
<ul> <li>(M) Plastic washers (24)</li> <li>(N) Fixture loop (1)</li> <li>ACCESSORIES &amp; QTY ENCLOSED:</li> <li>(A)Plastic wire connector (3)</li> <li>(B) Mounting screw (2)</li> </ul>				

## ASSEMBLY & INSTALLATION INSTRUCTIONS:

- 1. Carefully remove the fixture from the carton and check that all parts and accessories are included as shown in the above illustration
- 2. Turn off power

Before you start to make installation, NEVER attempt any work without shutting off the electricity until the work is done. A). Go to the main fuse, or circuit breaker, box in your home. Place the main power switch in the "OFF" position. B). Place the wall switch in the "OFF" position

3. Unscrew the knob ball (G) from canopy (E) then remove the mounting plate (C)



uolfin@newdecorworld.com

FIXTURE

GROUND

CUPPED

WASHER

4. 1) Fix the arm (J) to the fixture loop (N) with screws (I). 2) Insert the glass (K) and the plastic washer (M) into the socket on the arm (J) and secure with a nut (L).

- 4. 1) According your desired hanging heigh to choose and use the tubes (H). then pass the wires and the ground wire through the tubes(H) the swivel joint (F) and the canopy (E)
  - 2) Thread the chosen tubes (H) and the canopy (E) with swivel joint(F) together. Hand tighten until snug.

Attach the mounting plate (C) to outlet box with the mounting screws(B) 5.

В



А

OUTLET BOX

GROUND

GREEN GROUND

SCREW

Connect wires as below wires connecting shown. TAKE NOTE OF YOUR COLOR OF FIXTURE ,NEVER **CONNECT** 

# WIRES TO GROUND WIRES

FIXTURE

GROUND

DIMPLES

Connect ground wire according to below chart

OUTLET BOX

GROUND

GREEN GROUND

SCREW



B



Н

М





Page: -3-/4



9. Check everything is already installed properly, then you could turn on the light. Enjoy !

# CLEANING

To clean, wipe fixture with a soft cloth. Clean glass with a mild soap. Do not use abrasive materials such as scouring pads or powders, steel wool or abrasive paper.

# ORDERING PARTS

Keep this sheet for future reference, and in case you need to order replacement parts. All parts for this fixture can be ordered from place of purchase. Be sure to use exact wording from illustration when ordering parts.