


ASSEMBLY INSTRUCTIONS


ITEM NOTE: WF302052 DINING TABLE








If you have any questions, please feel free to contact us.
Email: lowes.team@qualfurn.net




IMPORTANT NOTE :

- 1 PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED .
- 2 BEFORE YOU BEGIN , KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP
- 3 DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTILL THE TABLE FULLY SET-UP



| Part List For One | | | Hardware List For One | | |
|-------------------|---|------|-----------------------|--|------|
| No. | Hardware Description | Q'ty | No. | Hardware Description | Q'ty |
| A |  Table top | 1pc | 1 |  Bolt Ø5/16" x 50mm | 8pcs |
| | | | 2 |  Lock washer Ø5/16" x13x1.5mm | 8pcs |
| | | | 3 |  Flat washer Ø5/16" x16 x1.5mm | 8pcs |
| B |  Table leaf | 1pc | 4 |  Allen key 4 x 60 mm | 1pc |
| C |  Table Leg | 4pcs | | | |

Step 1



Step 2

