

CENTRAL AIR CONDITIONER COVER – ROUND

Fits most round residential units.

Protects air conditioner from damage caused by freezing water and debris.

Easy to Use:

1. Be sure unit is clean and dry.
2. Place cover over compressor unit and pull down as far as possible.
3. Wrap elastic straps around compressor unit.
4. Fasten hook on elastic strap into ring to complete installation.

WARNING: Damage to air conditioner system may occur if unit is operated while cover is on compressor unit. Remove cover before operating system.

CUBIERTA DE AIRE ACONDICIONADO CENTRAL – REDONDO

Se adapta a la mayoría de las unidades residenciales redondas.

Protege al aire acondicionado del daño provocado por el agua helada y los desechos.

Fácil de usar:

1. Asegúrese de que la unidad esté limpia y seca.
2. Coloque la cubierta sobre la unidad del compresor y tire de ella hacia abajo lo más que se pueda.
3. Asegure las correas elásticas alrededor de la unidad del compresor.
4. Ajuste el gancho a la correa elástica dentro del anillo para finalizar la instalación.

ADVERTENCIA: El sistema del aire acondicionado puede sufrir daños si la unidad se pone en marcha mientras la cubierta esté colocada sobre la unidad del compresor. Retire la cubierta antes de poner en marcha el sistema.



QUESTIONS? | PREGUNTAS?
800.654.8454
MDBUILDINGPRODUCTS.COM

