

PROJECTIM - SMART LED BR30 v2

BRANDBLUE SKY WIRELESS

DATE03.05.2017

SCENA

VEROLOO

TYPECUSTOM

TEAM MIGHT

ARIEL MENDOZA

FILE

IM

BR30

BR30


BR30

BR30

BR30

PIXELWARPS

STUDIOS



File Name: IM\_BR30-60100S\_v.02.00.ai

Constructed: 4" w x 6" h

Dimensions

Flat8.25" w x 6.25" h (per spread)

Dimensions:

Bleed

Sheet Trim

Sheet Score

Inner Die Cut / Msr

Inner Carton Score

Crop Marks / Info

Perforation

Feature Area

Unit Area

Glue Area

Blue Sky

WIRELESS

ADVANCEDCONNECT

LED BLUETOOTH®


SMART SYNC

BULB + SPEAKER

Thank you for purchasing our new **AdvancedConnect LED Bluetooth® SMART SYNC Bulb + Speaker**. Embrace the new style and convenience from Blue Sky Wireless to enjoy your music wirelessly and in style anywhere throughout your home.

FIRST THING'S FIRST!

✔ To ensure the best operation, download the latest instruction manual from BlueSkyW.com and check your app store for the latest updates.



Scan the QR code with your smartphone to download the FREE app **BSW-SYNC** or go to [www.BlueSkyW.com](http://www.BlueSkyW.com).

You may also go to your phone vendor's app store to download the app directly. Search for **BSW-SYNC** to download.

Download on the App Store

GET IT ON Google Play


INSTALL YOUR BULB!

✔ Gently install your **LED Bluetooth® SMART SYNC Bulb + Speaker** into your preferred lighting fixture. Note: this item is compatible with recessed lighting.

✔ Turn your lighting fixture's appropriate electric power ON to ensure proper operation.

Page 2

SYNCING YOUR SMART DEVICE to YOUR NEW BSW BULB




After you have downloaded the **BSW-SYNC** app from your App Store, you will have the following icon on your smart device.

✔ Open the Settings in your Bluetooth® enabled smart device and make sure Bluetooth is turned ON.

✔ Locate the device named **BSW-SYNC** and select it. Your smart device will confirm a successful wireless connection.

NOTE:

If you already have multiple bulbs grouped together, you may see several BSW-SYNC devices listed here. You only need to select ONE.





Page 3

HOW TO USE BLUE SKY BSW-SYNC WIRELESS APP

The app will let you adjust all of the settings and colors on your new **LED Bluetooth® SMART Bulb + Speaker**. To interact with your new **BSW SMART SYNC** bulb please follow the directions below:

After downloading and launching the **BSW-SYNC** app, you will be greeted with the following screen:



When you have your bulb installed and powered on, pressing the  menu icon will bring up the main menu where you can select your function.

LED CONTROL

Tap here to select which bulb group and bulb you wish to control.

MUSIC

This section accesses the music on your smart device for playback.\*


TIMER

Select here to add on an alarm for light activation or a sleep mode target.

BLUETOOTH CONNECT

This lets you access all of the Blue Sky Wireless devices within your home.

COLOR CONTROL



1 Tap here to power on and off your selected light and/or light group.

2 Select any color hue by tapping a part of the color wheel.

3 Tap here to select between color and white light.

4 Select from 4 different lighting presets.


5 Slide here to choose brightness.

6 Slide here to choose the speed at which your color hues change.

\*You can enjoy wireless music using the BSW app or the music app of your choice!

Page 4


HOW TO USE BLUE SKY BSW-SYNC WIRELESS APP



1 Tap here to return to the color control screen.


2 Here is where you can find all of the light devices installed in your home.

3 The **GROUP** tab contains all of the light devices within the selected group.

4 The Menu icon () opens the main menu sidetab to access functions.

LIGHT SELECTION SCREEN

Here you can set groups by room and identify which bulb(s) you wish to control. You can sync up to 12 Blue Sky bulbs together per group.



1 Tap here to add an alarm to a single bulb or to one of your groups.

2 The **TIMER** tab gives you a countdown timer that will automatically turn the bulb off after a specific amount of time.

3 Choose the exact time for the light and speaker to automatically turn on as an alarm or to turn off as a timer.

ALARM & TIMER SCREEN

(Available with the June 2017 App Update)

NOTE:

Always be sure to check your App store for new updates and check our website, [www.BlueSkyW.com](http://www.BlueSkyW.com), for the latest instruction manual.

• **NOTE** – Always be sure to check your APP store for new updates and check our website – [www.BlueSkyW.com](http://www.BlueSkyW.com) - for the latest instruction manual.

Page 5

SAFETY INSTRUCTIONS

• Risk of fire or electric shock. If not qualified, do not attempt to install. Contact a qualified electrician./Risque d'incendie ou de choc électrique. L'installation des luminaires à DEL nécessite une connaissance des systèmes électriques des luminaires. Si vous n'êtes pas qualifié, ne tentez pas d'installer l'article. Faites appel à un électricien qualifié./ Riesgo de incendio o descargo eléctrico. La instalación de la luz LED necesita el conocimiento de sistemas eléctricos de luminarias. Si usted no cuenta con dicho conocimiento, no intente instalar. Póngase en contacto con un electricista calificado.

• Risk of fire. MINIMUM 90°C SUPPLY CONDUCTORS./Risque d'incendie. CONDUCTEURS D'ALIMENTATION D'AU MOINS 90 °C./Riesgo de incendio. CONDUCTORES DE ELECTRICIDAD PARA 90° C COMO MINIMO

• Disconnect power at fuse or circuit breaker before installing or servicing./Coupez l'alimentation électrique depuis le panneau de fusibles ou de disjoncteurs avant d'installer l'article ou d'en effectuer l'entretien./Desconecte el suministro eléctrico en la caja de fusibles o interruptor de circuito antes de instalar o realizar mantenimiento.

• No user serviceable parts inside. To avoid electrical shock, do not disassemble product./Ne contient aucune pièce réparable par l'utilisateur. Afin de prévenir les chocs électriques, ne démontez pas l'article./No hay piezas que sean de utilidad para el usuario en el interior. Para evitar descargas, no desensamble el producto.

• This product is not intended for use in emergency light fixtures or exit signs. Not for use where exposed directly to the weather or water./Cet article n'est pas conçu pour une utilisation dans un luminaire d'urgence ou une enseigne de sortie. Ne convient pas aux endroits directement exposés aux intempéries ou à l'eau./Este producto no está diseñado para usarse en lámparas de emergencia o señales de salida. No lo use donde esté expuesto directamente al clima o al agua.

Page 6

WARRANTY

The manufacturer warrants this lighting fixture to be free from defects in materials and workmanship for a period of one (1) year from the date of original purchase by the consumer. We will repair or replace (at our option) the unit in the original color and style if available, or in a similar color and style if the original item has been discontinued, without charge, exclusive of bulbs. Defective units must be properly packed and returned to the manufacturer with a letter of explanation and your original purchase receipt showing date of purchase. Call 1-954-866-8048 to obtain a Return Authorization number and an address where to ship your defective product.

Note: No C.O.D. shipments will be accepted. The liability of the manufacturer is in any case limited to replacement of the defective light fixture product. This warranty is void if damage or defect has resulted from accident, abuse, misuse or faulty repairs. In no event will liability extend to any consequential, special, incidental or direct damage of any kind arising out of the use or misuse of this product. Some states do not allow the exclusion or limitation of incidental or consequential damages so the above exclusion or limitation may not apply to you. The manufacturer will not be liable for any other loss, damage, or injury which is caused by the product. This limitation upon the liability of the manufacturer includes any loss, damage, or injury which is (I) to person or property or otherwise; (II) incidental or consequential in nature; (III) based upon theories of warranty, contract, negligence, strict liability, tort, or otherwise; or (IV) directly or indirectly related to the sale, use, or repair of the product. This warranty gives you specific rights, and you may also have other rights which vary from state to state. Proof of purchase is required to exercise the warranty.




Page 7


CHECK US OUT ONLINE

Please keep this instruction manual handy in case you have any questions on operation of your **LED Bluetooth® SMART SYNC BULB + SPEAKER** or if you need to contact Customer Service.

Check out more innovative lighting products from Blue Sky Wireless at our website on [www.BlueSkyW.com](http://www.BlueSkyW.com)

Follow us at:

 **BLUESKYWIRELESS**



LED Bluetooth®

COLORCHANGING

SMART BULB

Compatible with all A19 light bulb fixtures.

Page 8

COMPANY & MISC. INFORMATION

Blue Sky

WIRELESS

Model no. 60100S

ADVANCED CONNECT LED BLUETOOTH® SMART SYNC BULB+SPEAKER

If you run into any technical difficulties while operating your new bulb, please contact our support team by email or at our Blue Sky Wireless Customer Support line from 9 AM to 5 PM EST Mon-Fri. Support@BlueSkyW.com • 954.866.8048 Coral Springs, FL 33076 • USA

WARNING

Important safety information - read all instructions and notices before installation.

• No user serviceable parts inside. To avoid electrical shock do not disassemble product.

• This product is not intended for use in emergency light fixtures or exit signs. Not for use where exposed directly to the weather or water.

• This product contains a chemical known to the state of California to cause cancer, birth defects or other reproductive harm.

CAUTION

Turn power off before inspection, installation or removal.

Use only on 120 VAC, 60Hz circuits.

©2017 Blue Sky Wireless, LLC.

All rights reserved. Blue Sky Wireless and the Blue Sky Wireless logo are trademarks of Blue Sky Wireless, LLC, registered in the U.S. PATENT PENDING

Apple and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc., registered in the U.S. and other countries. Google Play and the Google Play logo are trademarks of Google Inc.

