


CAULK CORD WEATHERSEAL

Easy to Use:


- No caulk gun required
- Seal window panes
- Seals cracks & prevents drafts
- Plug holes

1. Make sure surface is clean and free of dirt, moisture, grease and old caulk.
2. Carefully peel top layer of cord “beads”. Separate individual beads according to desired width of gap.
3. Press cord into opening and form to desired shape. For large gaps, use several cord beads.
4. Place unused cord back in carton for future use.




Seal cracks around windows and door frames

Sella rajaduras alrededor de los marcos de ventanas y puertas



Seal cracks around window panes

Sella rejaduras alrededor de vitrales



Plug holes around plumbing

Tapa agujeros alrededor de plomería

CINTA SELLADORA DE MASILLA

Fácil de usar:

- No requiere pistola calafateadora
- Sella el vidrio de ventana
- Sella ranuras y previene corrientes de aire
- Tapa Agujeros

1. Asegurarse que la superficie esté limpia y libre de tierra, humedad, grasa y de masilla vieja.
2. Pelar cuidadosamente la capa superior de la “tira”. Separar las tiras individualmente de acuerdo al grosor de la grieta o vacío por rellenar.
3. Presionar la tira dentro de la abertura y darle la forma deseada. Para grietas grandes usar varias tiras.
4. Colocar las tiras sobrantes en la caja para usarlas en el futuro.



QUESTIONS? | PREGUNTAS?
800.654.8454
MDBUILDINGPRODUCTS.COM

