












ORNAMENT DISPLAY TREE HMI-665

Assemble components on a soft, clean surface
to avoid scratching or damaging the finish.



Inspect packaging to ensure all
parts are accounted for before
disposing of packing materials.



No.	PARTS	QTY.
A1	 Inner Base Leg**	1
A2	 Base Leg	1
B1	 Center Pole	1
B2	 Center Pole with Star	1
C	 Bolt and Nut **remove from part A1	1
D	 32" Branch	4 PC SET
E	 27" Branch	2 PC SET
F	 22" Branch	2 PC SET
G	 19" Branch	2 PC SET
H	 16" Branch	2 PC SET

! HELPFUL HINT


Sunnydaze Decor advises reading this manual fully, and assembling the item soon after purchase. Check that all parts are accounted for and familiarize yourself with the assembly before beginning.

Save this manual for future reference.

ASSEMBLY

STEP 1


A1: 1
A2: 1
C: 1



Remove Bolt and Nut (C) from Inner Leg Base (A1).
Cross Inner Base Leg (A1) through Base Leg (A2).
Secure leg components using Bolt and Nut (C).

STEP 2

B1: 1
D: 4 PC SET



NOTE: branch set spacing is approximately 7". Install each set with branches facing as shown; do not fully tighten wing screws until Step 4 is complete.

With the tapered end of Center Pole (B1) facing upwards, cross two 32" Branch (D) and gently affix, as shown. Repeat to affix second set of 32" branches.


STEP 3

B2: 1
E: 2 PC SET
F: 2 PC SET
G: 2 PC SET
H: 2 PC SET



Cross 16" Branch Set (H) and slide onto Center Pole with Star (B2) and gently affix near the top. In size order, affix 19", 22" and 27" Branch Sets (G, F, E) below the 16" set, ensuring each set is evenly spaced; approximately 7".

STEP 4



Insert assembled components from Step 2 into the base legs and secure using the wing screw on Inner Base Leg (A1).

Place assembled components from Step 3 onto the tapered end of Center Pole with Star (B2).

If satisfied with branch spacing, tighten the wing screws on all branch sets.

! SAFETY STATEMENTS & WARNINGS !

- Recommended for indoor use only.
- Do not hang heavy objects from the hooks.
- Ensure weight is evenly distributed on the stand to prevent it from tipping over.
- This is not a toy. Always supervise children and pets.

Any modification to the product or failure to follow recommended care will void the product warranty.

! WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.