

Installation Precautions:

	Possible Cause	Corrective Action
Bulb will not light.	1. Bulb is burned out.	1. Replace light bulb.
	2. Power is off.	2. Make sure power supply is on.
	3. Cord not plugged in.	3. Make sure cord is plugged into the outlet.
	4. Circuit breaker off.	4. Make sure circuit breaker is to the 'on' position.
Fuse blows or circuit breaker trips when light is turned on.	1. Exposed wire	1. Discontinue use. Unplug unit from the wall and contact a qualified electrician

PRODUCT MAINTENANCE:

1. To clean simply wipe with a soft dry cloth.
2. Do not use any cleaners with chemicals, solvents or harsh abrasives.

FEATURES:

1. Durable easy to maintain finish; simply wipe with a clean soft cloth to keep looking new.
2. Using On the table switch Makes this light easier to switch on and off and easier to operate
3. Popular E26 (E27) lamp holder may be fitted with a CFL equivalent energy-saving bulb..

TOOLS REQUIRED FOR ASSEMBLY:



1 ea—50-watt maximum 1-way type
A bulb (or CFL equivalent)
(not included)

INSTRUCTION MANUAL

Retro Table Lamp



Thank you for purchasing this product