



# RODUCT INSTRUCTION



## KF150169-01






### **IMPORTANT INFORMATION!**

please read the entire manual before starting to assemble and/or using this product. follow the manual thoroughly and keep it for further reference.





### **AVOID SCRATCHES!**

In order to avoid scratching this furniture should be assembled on a soft layer-could be a rug.



### **IMPROVE EFFICIENCY !**

Try to find a partner to install with you, which can speed up the installation efficiency and shorten the time.



### **ANTI-TOPPLE WARNING !**

Overturned furniture can cause serious or fatal crush injuries. To prevent tipping over, be sure to use the wall attachment, if not included with this product. Please purchase the wall attachment that fit your wall. If unsure, seek professional advice. Please read and follow each step of the instructions carefully.


### **IMPORTANT !**


It is important that any product which is assembled using any kind of screw is re-tightened 2 weeks after assembly, and once every 3 months - in order to assure stability through-out the lifespan of the product.

For regular maintenance and cleaning of the product, for the frame, please use a rag dipped in neutral detergent to fully wipe it, and then dry it with a clean rag. For glass materials, wipe with a rag dampened with water glass cleaner, and then dry with a dry rag.


Do not use an electric screwdriver, and do not use too much force when installing, because the board is easy to break.

# Parts List / Teileliste






Please prepare the following tools




When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

A x 78+5



$\phi 5 \times 31 \text{ mm}$

B x 78+5



$\phi 15 \times 11 \text{ mm}$

C x 51+5



$\phi 8 \times 30 \text{ mm}$

D x 3




L=350mm

E x 24+2




$\phi 3 \times 12 \text{ mm}$

Fx4




$\phi 3.5 \times 17 \text{ mm}$

G x 5




$\phi 6 \times 25 \text{ mm}$

H x 18+1




$\phi 6 \times 35 \text{ mm}$

J x 4



$\phi 3.5 \times 14 \text{ mm}$

K x 1



O x 1



L x 24+2




$\phi 3 \times 12 \text{ mm}$

m x 6




N x 80+5



O x 1



P.x 3




$\phi 4 \times 18 \text{ mm}$


Q x 6



$\phi 6 \times 30 \text{ mm}$



Please prepare the following tools




When installing, please carefully confirm whether each screw corresponds to the manual, accessories with similar shapes can be distinguished by size

I x 8




Ø3.5x15mm

R x 3




Ø6 x 40mm

S x 2




Ø6x80mm

T x 4




U x 5




Ø6 x 40mm

V x 2



Ø6 x 12mm


W x 5



X x 2




Y x 6




Ø 6x20 mm


White nut






X3

1

Dx1  
  
 L=350mm

Ex4  
  
 $\varnothing 3 \times 12 \text{ mm}$






2


A x 4



Ø5x31mm



180°



3

Cx3





Ø 8 x 30 mm

Hx18



Ø 6x35 mm





4

Ax14





Ø5x31mm

Cx16



Ø8x30mm

Xx2








5

Bx4



Ø15x11mm



6



Ax2  
Ø5x31mm.













Sx2  
Ø6x80mm



C x 2  
Ø8 x 30mm



Bx2  
Ø15x11mm







7

Bx4



Ø15x11mm



8

Bx4






Ø 15x11mm

Gx2



Ø 6x25mm



9

Dx1



Ax3



Ø 5x31mm

Cx2











Ø 8x30mm

Ex4



Ø 3x12 mm



10

Dx1



Ax3



Ø5x31mm

Cx2









Ø8x30mm


Ex4



Ø3x12 mm



180°



# 11

Bx4



Ø15x11mm

Ax4







Ø5x31mm

Cx4



Ø8x30mm





# 12

Ax2



Ø5x31mm

Cx2







Ø8x30mm

Bx6



Ø15x11mm




13

G x 3





Ø6X25mm

R x 3



Ø6X40mm



14

Ax4






Ø5x31mm

Cx4



Ø8x30mm







15

Bx4



Ø15x11mm








16

Bx6



Ø15x11mm




17

Q x 6



Ø6 x 30 mm



# 18

Cx3






Ø8x30mm

Yx6




Ø6x20mm





19

Ax18



Ø5x31mm





20

Cx16








Ø8x30mm

Bx16



Ø15x11mm



21



Jx4



Jx8



Ø 3.5x14mm



22


O x 1






W x 5



U x 5



Ø6 x 40mm





23

Lx24



Ø 3x12mm



24

F x4



Ø 3.5x17mm


J x4






J x16




Ø 3.5x14mm



x2



x2





25

i x8



Ø 3.5x15mm

T x4





26

V x 2





Ø6 x 12mm



27

Kx1





28

Ax8







Ø5x31mm

Bx8













Ø15x11mm



x2

29

<p>Ax8</p>  <p>∅ 5x31mm</p>	<p>Bx8</p>  <p>∅ 15x11mm</p>	<p>P.x 2</p>  <p>∅ 4 x 18mm</p>		
--	---	--	--	---



30

Ax4






Ø5x31mm





Bx4





Ø15x11mm



# 31

<p>Ax4</p>  <p>∅5x31mm</p>	<p>Bx4</p>  <p>∅15x11mm</p>	<p>P.x 1</p>  <p>∅4 x 18mm</p>		
---	--	---	--	---



32



Dx3



Ex12





Ø 3x12mm



x3

33









34

mx6



NX80





Serious or fatal crushing injuries can occur from furniture tip-over.  
To further reduce the risk of serious injury and death from tip-overs:

Schwere oder tödliche Quetschverletzungen können durch Umkippen von  
Möbeln auftreten.  
Um das Risiko schwerer Verletzungen und Todesfälle durch Umkippungen  
weiter zu reduzieren.



# WARRANTY

## WARRANTY CLAIMS

- There is a 30-day warranty for broken furniture or any other problems that do not work properly. The warranty will start from the date of purchase which must be verified by proof of purchase.
- Before making a claim, we may be able to answer your query, simply call us. Please leave your purchase order number, along with some details of the problem, if you want a replacement part. We will arrange within 48 hours. If there is out of stock, we will reply with a shipping date.
- The product must be used in accordance with the instructions provided. For health reasons.
- For other reasons, if the furniture needs to be returned, it must be cleaned and dried and operated within 30 days of receipt.

## Type of Warranty Claim

- Failure to follow the furniture instructions will invalidate the warranty. Attention please.
- Does not include damage during installation, but includes damage during transportation.

## Scope of responsibility

- Shall not bear any responsibility for misuse or user damage and / or loss of parts during the installation of furniture.
- After using, the damage and scratches of the furniture are not covered by the warranty.

## The Warranty Relates to All Bought in The Us and Covers The Following Areas

- Sheet parts: 1 month from the date of purchase.
- Electrical parts: 1 month from the date of purchase.

**If you haven't received all your packages, wait for 3-5 more days as they may still be in transit Contact the seller or delivery service iif the expected delivery date has passed and you haven't received any packages, and do so promptly to avoid further delays**

***Please note the product has 2 packages, and this is the package2***

# RETURNS

## CHANGED YOUR MIND AND NEED TO RETURN YOUR ITEM?

### PLEASE FOLLOW THE BELOW INSTRUCTIONS:

- If you have purchased and have simply changed your mind, follow the retailer's instructions for returns.

### DEFECTIVE ITEMS

- If your item is defective in any way, i.e. it doesn't work but you can't identify why, in the first instance, please call us.

### DAMAGED ITEMS

- If you receive an order with obvious shipping damage from the retailer, then we suggest the delivery is refused. If the delivery has been accepted and then shipping damage is found, please follow the specific instructions advised by the retailer.  
In all circumstances please save all packaging material and paperwork for the order. Please be aware that if you dispose of packaging material or attempt to return the merchandise without contacting the fulfiller, you jeopardise your chances of making a claim, and you may not receive a credit for the return.